

Mechatronics

NS500 (PROFIBUS-DP)

NS300 (DEVICE-NET)

QUICK REFERENCE

OMRON

QUICK REFERENCE: NS500 (PROFIBUS-DP) NS300 (DEVICE-NET)


THIS MANUAL CONTAINS:

- 1.- OPTION BOARD INSTALATION.**
- 2.- CONFIGURATION.**
- 3.- PROGRAMMING.**
 - 3.1- DATA MANAGEMENT.**
 - 3.2- PARAMETER COMMANDS.**
 - 3.3- MOVEMENT COMMANDS.**
- 4.- SOFTWARE NSXXXSETUPTOOLS.**
- 5.- FIELD BUS CONFIGURATION.**
 - 5.1- PROFIBUS DP**
 - 5.2- DEVICE-NET**


1- NS500/NS300 INSTALLATION.

Following steps should be used to install the NS500/NS300 into a W servodriver:

1.- Take off the protector in the CN10 connector situated in the right side of the servodriver.





2.- Clamp the option board to the servodriver using the pieces in the bottom of the option board.



3.- Push the board following the arrow direction and clamp the option board using the upper piece.

4.- To connect the board ground cable to the servodriver use a Phillips screw M3x10 (up to 1kW) and M4x8 (up to 15 kW) with the point "G".





Option board NS500
PROFIBUS-DP

- x10:** Rotatory Switch for slave number
- x1:** Rotatory Switch for slave number
- CN11:** (RS232C) communication software connector (NsxxxSetuptools)
- COMM:** PROFIBUS communication state Led (green, red)
- ERR:** Option board error led
- CN6:** PROFIBUS-DP communication connector
- CN4:** I/O connector (close loop encoder input and emergency stop)

The reference code for the different connectors is this one:

20 PINS RIGHT ANGLE RECEPTACLE	CN4	Port
SERVOS CN4-V1	CN11	Port
“SUB-D 9 pins male connector”	CN6	Port (PROFIBUS-DP)

The configuration for the software cable to use the **NSxxx SETUP TOOL** software is this one:


NS500 CN11	Details	PC (9 pines)
1 (TXD)	Serial data output	2 (RXD)
2 (RXD)	Serial data input	3 (TXD)
3 (GND)	Ground	5 (GND)
4 (GND)	Ground	5 (GND)

The CN6 connector is used for the PROFIBUS DP bus and the configuration is:

Pin 3:	RXD/TXD-P	Send / receive positive data
Pin 8:	RXD/TXD-N	Send / receive negative data
Pin 5:	DGND	Ground
Pin 6	VP	+5V

The communication cable between the Profibus-DP master and slave is flat style (direct), it means 3-3 and 8-8.

Option board NS300
DEVICE-NET



The code references for the different connectors are these ones:

20 PINS RIGHT ANGLE RECEPTACLE
SERVOS CN4-V1

CN4 port
CN11 port

The communication cable for the programming software **NSxxx SETUP TOOL** is this one:

NS300 CN11	Details	PC (9 pines)
1 (TXD)	Serial data output	2 (RXD)
2 (RXD)	Serial data input	3 (TXD)
3 (GND)	Ground	5 (GND)
4 (GND)	Ground	5 (GND)

The communication cable between the Device-Net master and the slave is a flat style (direct) following the connector colours.

2- CONFIGURATION

When an option board NS500/NS300 is connected with a servodriver a new system is formed with different characteristics than the servodriver by itself.

- **PARAMETERS:** Some parameters of the servodriver are no more time useful (for example, speed and torque control parameters, because with the option board the control method only could be position control). Some other parameters are added (for example, Pn823: Origin search method, etc...)
- **INPUT / OUTPUT:** Like the parameters some inputs disappear and other specific one appears. The inputs and outputs are no more time configurable and some of them are fixed on CN1 and CN4 of NS500 and NS300.
- **Programming software NSxxx SETUP TOOL:** It should be used to program and monitor the status of NS300/NS500 because new parameters are not accessible using the servodriver display.

2.1.- INPUTS / OUTPUTS

CN1 CONNECTOR (SERVODRIVER)


INPUTS

CN1-47		+24VIN Input common. 24 VDC are needed to supply the inputs.
CN1-41	/DEC	Origin proximity signal (HOMING function).
CN1-42	POT	Positive overtravel limit.
CN1-43	NOT	Negative overtravel limit.
CN1-44	EXTP	External positioning signal.
CN1-45	ZERO	Zero point signal (origin). This one is used to fix an origin without the encoder Z signal.

OUTPUTS

CN1-31, 32	/ALM	Alarm: Turns OFF when an error is detected.
CN1-25, 26	COIN	Positioning complete outputs (INPOSITION).
CN1-27, 28	BKIR	Brake interlock output.
CN1-29, 30	READY	Servodriver without alarm and ready.
CN1-37/38/39,1	AL01/AL02/AL03	Alarm output code.

There are no encoder signals.




CN4 CONNECTOR (OPTION BOARD NS500 / NS300)

INPUTS

CN4-11	+24V/COM	Input common. 24VDC for the inputs power supply.
CN4-9	EMSTOP	Emergency stop input
CN4-14	PC	External encoder input phase Z.
CN4-15	/PC	External encoder input phase /Z
CN4-16	PA	External encoder input phase A
CN4-17	/PA	External encoder input phase /A
CN4-18	PB	External encoder input phase B
CN4-19	/PB	External encoder input phase /B
CN4-1/2/3	PG 0V	Ground

OUTPUTS

CN4-12, 13	NOTCH1	Notch output 1 (Turns On when actual position is inside range 1).
CN4-10, 20	NOTCH2	Notch output 2 (Turns On when actual position is inside range 2).



CLOSE LOOP WITH EXTERNAL ENCODER

In the NS500/NS300 is possible to add an external encoder to close the position control loop. To make it work is necessary 5V line-driver encoder output and connected directly to the controlled axis.

Only two parameters are needed to configure the external encoder when this one has been connected.

Pn206: External encoder pulses/revolution

Pn002.3: to enable the close loop

- 0 = disable, not used.
- 1 = Close loop encoder without Z phase
- 2 = Close loop encoder with Z phase
- 3 = Close loop encoder without Z phase used in reverse mode
- 4 = Close loop encoder with Z phase used in reverse mode.

2.2.- PARAMETERS

The parameters that remain in the servodriver are these ones:

Category	Parameter Number	Name	Unit	Setting Range	Default Setting
Function Selection Parameters	Pn000	Pn000.0 Rotation direction Pn000.1=1 Control method (fixed to position) Pn000.2 Serial slave address (See note 3)	—	—	0010
	Pn001	Pn001.0 Stopping method for Alarm or Servo-off Pn001.1 Overtravel stopping method Pn001.2 AC/DC power supply Pn001.3 Warning output selection (See notes 1 and 3)	—	—	0000
	Pn002	Pn002.0 Not used Pn002.1 Not used Pn002.2 Absolute encoder Pn002.3 Close loop encoder (See note 3)	—	—	0000
	Pn003	Function Selection Application Switches 3	—	—	0002
Gain Parameters	Pn100	Speed Loop Gain	Hz	1 to 2000	40
	Pn101	Speed Loop Integral Time Constant	0.01ms	15 to 51200	2000
	Pn102	Position Loop Gain	s ⁻¹	1 to 2000	40
	Pn103	Inertia Ratio	%	0 to 10000	0
	Pn104	Not Used	—	—	—
	Pn105	Not Used	—	—	—
	Pn106	Not Used	—	—	—
	Pn107	Bias	Rpm	0 to 450	0
	Pn108	Bias Width Addition	Ref. units	0 to 250	7
	Pn109	Feed-forward	%	0 to 100	0
	Pn10A	Feed-forward Filter Time Constant	0.01ms	0 to 6400	0
	Pn10B	Gain-related Application Switches (See note 3)	—	—	0000
	Pn10C	Mode Switch Torque Reference	%	0 to 800	200
	Pn10D	Mode Switch Speed Reference	Rpm	0 to 10000	0
	Pn10E	Mode Switch Acceleration	10rpm/s	0 to 3000	0
	Pn10F	Mode Switch Error Pulse	Ref. units	0 to 10000	0
	Pn110	Online Autotuning Switches (See note 3)	—	—	0010
	Pn111	Speed Feedback Compensation (See note 2)	%	1 to 100	100
	Pn112	Reserved parameters (Do not change)	%	0 to 1000	100
	Pn113		—	0 to 10000	1000
Pn114	—		0 to 400	200	
Pn115	—		0 to 1000	32	
Pn116	—		0 to 1000	16	
Pn117	%		20 to 100	100	
Pn118	%		20 to 100	100	
Pn119	s ⁻¹		1 to 2000	50	
Pn11A	0.1%		1 to 2000	1000	
Pn11B	Hz		1 to 150	50	
Pn11C	Hz	1 to 150	70		
Gain Parameters	Pn11D	Reserved parameters (Do not change)	%	1 to 150	100
	Pn11E		%	1 to 150	100
	Pn11F		ms	1 to 2000	0
	Pn120		0.01 ms	1 to 51200	0
	Pn121		Hz	10 to 250	50
	Pn122		Hz	0 to 250	0
	Pn123		%	0 to 100	0
Position Parameters	Pn200	Position Control Reference Selection Switches (See note 3)	—	—	0000
	Pn201	Not used	p/r	16 to 16384	16384
	Pn202	Not used (Electronic gear Pn810)	—	1 to 65535	4
	Pn203	Not used (Electronic gear Pn811)	—	1 to 65535	1
	Pn204	Not Used	—	—	—
	Pn205	Multi-turn Limit Setting (See notes 1 and 3)	rev	0 to 65535	65535
	Pn206	Close loop encoder revolutions	—	—	—
	Pn207	Not used (See note 3)	—	—	0001
Pn208	Not used (See note 3)	0.01ms	0 to 6400	0	
Not Used	Pn300	Not Used	—	—	—
	Pn301	Not Used	—	—	—
	Pn302	Not Used	—	—	—
	Pn303	Not Used	—	—	—

Speed Parameters	Pn304	Jog speed by digital operator	—	—	—
	Pn305	Not Used	—	—	—
	Pn306	Not Used	—	—	—
	Pn307	Not Used	—	—	—
	Pn308	Speed Feed-Forward Filter Time Constant	0.01ms	0 to 65535	0
Torque Parameters	Pn400	Not Used	—	—	—
	Pn401	Torque Reference Filter Time Constant	0.01ms	0 to 65535	100
	Pn402	Forward Torque Limit	%	0 to 800	800
	Pn403	Reverse Torque Limit	%	0 to 800	800
	Pn404	Forward rotation external current limit	—	—	—
	Pn405	Reverse rotation external current limit	—	—	—
	Pn406	Emergency stop torque	—	—	—
	Pn407	Not Used	—	—	—
	Pn408	Torque Function Switches	—	—	0000
	Pn409	Notch Filter Frequency	Hz	50 to 2000	2000
Sequence Parameters	Pn500	Not Used	—	—	—
	Pn501	Not Used	—	—	—
	Pn502	Rotation Detection Level	rpm	1 to 10000	20
	Pn503	Not Used	—	—	—
	Pn504	Not Used	—	—	—
	Pn505	Overflow Level	256 ref.units	1 to 32767	1024
	Pn506	Brake Reference Servo OFF Delay Time	10ms	0 to 50	0
	Pn507	Brake Reference Output Speed Level	rpm	0 to 10000	100
	Pn508	Timing for Brake Reference Output during Motor Operation	10ms	10 to 100	50
	Pn509	Momentary Hold Time	ms	20 to 1000	20
	Pn50A	Input Signals Selection 1	—	—	8881 (fixed)
	Pn50B	Input Signals Selection 2	—	—	8888 (fixed)
	Pn50C	Not used	—	—	8888 (fixed)
	Pn50D	Not used	—	—	8888 (fixed)
	Pn50E	Output Signals Selection 1	—	—	3000 (fixed)
	Pn50F	Output Signals Selection 2	—	—	1200 (fixed)
	Pn510	Output Signals Selection 3	—	—	0000 (fixed)
	Pn511	Reserved (do not change)	—	—	8ED8 (fixed)
Pn512	Output Signals Reversal Settings	—	—	0000	
Other Parameters	Pn600	Regenerative Resistor Capacity (See note 4)	10 W	0 to capacity (See note 5)	0
	Pn601	Reserved parameter (Do not change)	—	0 to capacity (See note5)	0

The new parameters added in the option board are these ones :

Origin search parameters

Pn800	Homing mode
Pn801	Bit 0: Origin search direction
	Bit 1: Origin proximity input signal setting /DEC
	Bit 2: Origin input signal setting /ZERO
	Bit 3-15: -
Pn802	Homing feed speed
Pn803	Homing approach speed
Pn804	Homing Creep speed
Pn805	Final running distance for homing
Pn806	Home position signal output width
Pn809	Home position offset
Pn80A	Homing Accel/Decel time

Mechanical system parameters

Pn810	Electronic gear (numerator)
Pn811	Electronic gear (denominator)
Pn812	Coordinate system type
Pn813	Ref unit value per load shaft rotation (resolution)
Pn814	Backlash compensation value
Pn815	Backlash compensation direction
Pn816	Stored stroke limit (+)
Pn817	Stored stroke limit (-)
Pn818	Mechanical function selection
Pn819	Overtravel signal function select
Pn81A	Overtravel stopping method
Pn81B	Emergency stop signal function selection

Speed acceleration parameters

Pn821	Positioning feed speed
Pn822	Positioning acceleration time
Pn823	Positioning deceleration time
Pn824	Positioning 2-stage Acceleration/Deceleration switching speed
Pn825	Positioning 2-stage Acceleration/Deceleration time
Pn826	Positioning acceleration/deceleration time
Pn827	External signal positioning speed
Pn829	Acceleration/deceleration filter selection
Pn830	Feed operation reference unit of feed speed (Byte 4-7)
Pn831	Feed operation speed
Pn832	Feed operation acceleration time
Pn833	Feed operation deceleration time
Pn834	Feed operation 2-stage Accel/decel switching
Pn835	Feed operation 2-stage Accel/decel time
Pn836	Feed operation 2-stage Accel/decel profile
Pn840	Positioning exponential Accel/Decel time constant
Pn841	Positioning Accel/decal bias speed
Pn842	Positioning moving average time constant
Pn843	Maximum feed speed
Pn844	Step feed distance 1
Pn845	Step feed distance 2
Pn846	Step feed distance 3
Pn847	Step feed distance 4

Positioning

Pn850	Positioning completion range
Pn851	Positioning completion Time-Out time
Pn852	Positioning NEAR detection range
Pn853	Quick positioning (Station N° positioning)
Pn854	External signal positioning approach speed
Pn855	External signal positioning moving distance
Pn856	Function setting of external signal positioning
Pn85A	Station number

Positioning with multi stage feeding function

Pn861	Speed switching point number
Pn862	Feed speed at start
Pn863	Speed switching position 1
Pn864	Speed switching position 2
Pn865	Speed switching position 3
Pn866	Speed switching position 4
Pn867	Speed switching position 5
Pn868	Speed switching position 6
Pn869	Speed switching position 7
Pn86A	Speed switching position 8
Pn86B	Speed switching position 9
Pn86C	Speed switching position 10
Pn86D	Speed switching position 11
Pn86E	Speed switching position 12
Pn86F	Speed switching position 13
Pn870	Speed switching position 14
Pn871	Speed switching position 15
Pn872	Speed switching position 16
Pn873	Switching speed at position 1
Pn874	Switching speed at position 2
Pn875	Switching speed at position 3
Pn876	Switching speed at position 4
Pn877	Switching speed at position 5
Pn878	Switching speed at position 6
Pn879	Switching speed at position 7
Pn87A	Switching speed at position 8
Pn87B	Switching speed at position 9
Pn87C	Switching speed at position 10
Pn87D	Switching speed at position 11
Pn87E	Switching speed at position 12
Pn87F	Switching speed at position 13
Pn880	Switching speed at position 14
Pn881	Switching speed at position 15
Pn882	Switching speed at position 16

Passing point output positioning

Pn890	Notch signal setting
Pn891	Notch signal polarity select
Pn892	Notch output position 1
Pn893	Notch output position 2
Pn894	Notch output position 3
Pn895	Notch output position 4

System

Pn8FD	Error mask
Pn8FE	Parameter check sum rebuild
Pn8ff	Factory setting reset

Point table

Pn900	Target position 1
Pn931	Target position 2
Pn940	Feed speed for target 1
Pn971	Feed speed for target 50

ORIGIN SEARCH PARAMETERS

These parameters are related only with this function, speed, distance, operation type, etc... So they'll be explained in the origin search section of this guide.

MECHANICAL SYSTEM PARAMETERS

Gear ratio selection

These two parameters are used to define the ELECTRONIC GEAR or PULSE RATE, in other words the relationship between pulses (internally used by the driver) and the reference units (that are managed by the user).

Depending of the mechanical system coupled to the motor and the reference units select by the user different values should be applied to Pn810/Pn811

For example: With a 13 bits (2048ppr) servomotor with a gear reduction 1/5 and connected to a landscrew with 5mm/rev of pitch. If the user wants to use mm and use two decimals instead of pulses the calculation will be this one.

1 motor revolution = 2048pulsos x4(feedback) = 8192 pulses. With a gear reduction of 1/5 we need 5 rotation of the motor for each revolution of the gear: 1 rev = 8192 x 5 = 40960 puls es


Pn810/Pn811 = 40960 puls es / 500 (0.01mm); it means that 40960 feedback puls es correspond to 500 reference units, in this case 0.01mm.

The other mechanical system parameters are used to define lineal or circular coordinates, the backlash compensation, the software and hardware limits and the stop method for limits or alarms.

SPEED PARAMETERS, ACCELERATION AND DECELERATION

Several speeds and distance for different positioning commands and also the acceleration and deceleration time could be configured on this section.

In Pn826 and Pn829 is possible to set the acceleration/deceleration profile.



Where:

Pn822 is the acceleration time

Pn843 is the maximum speed

Pn824 is the switch speed to use the 2nd accel/decel time parameters


Pn825 is the 2nd accel/decel time

Pn823 is the deceleration time.

Is possible to apply a filter to these profiles in parameter Pn829:

- 0 → **None**
- 1 → **Exponential** with Pn840 as a time constant
- 2 → **Exponential with bias**, with Pn840 as a time constant and Pn841 as a bias speed. Filter only applied up the bias speed
- 3 → **S Curve** with Pn843 as a time constant

Is possible to apply filters 0 and 3 to any profile but filters 1 and 2 are only applicable to the profile without ramps.



POSITIONING PARAMETERS

These ones are used to define the external positioning and some status bits.

MULTI SPEED PARAMETERS

Are useful to define the 16 multi speeds and the positions where the multi-speeds will be applied.

NOTCH OUTPUT PARAMETERS

The parameters allow the definition and activation of NOTCH1 and NOTCH2 external outputs. This outputs turns on when the actual position is inside the defined range and when the position command include the Notch output.

POINT TABLE PARAMETERS


These parameters define the target position and the target speed for a positioning; up to 50 table points are available. To use this table positioning is necessary to use the point table command.

3- PROGRAMMING


The option boards NS500/NS300 for the W servos always work as 8 bytes mixed slaves, PROFIBUS-DP / DEVICE-NET. It means that each board uses 8 input bytes and 8 output bytes, these bytes are used to program or command the module (outputs) and monitor the status (inputs).

Depending of each function the 8 bytes format change. The functions could be spared into parameter command (write/read) and movement commands.

PARAMETER COMMAND FORMAT (WRITE /READ)



MOVEMENT COMMAND FORMAT



In both cases we have

General command bits

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
[0]	MOD	0	ALRST	ESTP	0	0	SVON	C_STRT

Where:

- MOD** is the **command type**, movement (0) or parameter read/write (1)
- ALRST** is the **alarm reset** command
- ESTP** is the **software emergency stop** bit negative logic
- SVON** is the **RUN (servo on) bit**
- C_STRT** is the bit that executes the selected command in the command code. Gives the **START** of a movement command

General status bits

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
[0]	MOD_R	READY	PWRON	ESTP_R	ALRM	WARN	SVON_R	C_STRT_R

Where:

- MOD_R** shows the command type, movement (0) or parameters (1).

READY shows that NS500/NS300 unit is **ready** to receive commands

PWRON shows that unit is powered (**Power ON**)

ESTP_R shows if the **emergency input** is active (0) or not (1).

ALM_R shows if option board is in **alarm**

WARN shows if the unit has detected some **warning (AL9x)** in the servo or in the NSxxx

SVON_R shows if the motor is in **RUN** or Baseblock

C_STRT_R shows if one movement command has been received (**C_STRT**)


3.1. - DATA MANAGEMENT

PROFIBUS-DP and DEVICE-NET works in byte level but Omron's PLCs works in word level so we'll find some differences depending of the bus master used in the network.

PROFIBUS-DP (C200HW-PRM21 master)

With Profibus-DP master the bytes are ordered in this way: First the most significative weight and follow by the less significative one.


Ex:



DEVICE-NET (C200HW-DRM21-V1 or CS1W-DRM21 master)


This devicenet masters works in reverse order compared with the Profibus: In this case the less significative weight bytes are allocated first and more significative one are placed after it.

Ex:



3.2. - PARAMETER COMMANDS

These commands are used to read and write parameters into the servodriver or into the option board also is possible to establish the zero point or define a position. The format is this one:



- The command codes are:
- 0000** No operation
 - 1000** Read parameter
 - 1001** Write parameter
 - 1010** Actual position definition
 - 1100** Read alarm
 - 1110** NSxxx module reset (Store parameters in FLASH RAM)

Here we can see some examples about these commands, for this examples we have used IR050 for outputs and IR350 for inputs (NS500) and channels 3200 and 3300 for the NS300.

3.2.1. - PARAMETER READ (Pn817: Negative software limit)

PROFIBUS-DP

1. Change the command code (1000b = 8h) → [1] = 08
2. Parameter number (817hex) → [2][3] = 08 17
3. Active the execution command bit C_STRT → change from [0]= 80 to [0]=81

It means:

c050 → [0][1] → 8008	When bit 050.08 turns On we have	c0350 → E008
c051 → [2][3] → 0817		c0351 → 0817
c052 → [4][5] → 0000		c0352 → FA0A
c053 → [6][7] → 0000		c0353 → 1F01

So the response is FA0A1F01h, that in this case is negative so it's necessary to convert using the two's complement (NOT+1). After applying the conversion the number we found is 5F5E0FFh that converted in decimal result 9999999.

Pn817 = -99999999

DEVICE-NET

1. Change the command code (1000b = 8h) → [1] = 08
2. Parameter number (817hex) → [2][3] = 17 08
3. Activate the execution command bit C_STRT → Change from [0]= 80 to [0]=81

It means:

c3200 → [1][0] → 0880	When bit 3200.00 turns On we have	c3300 → 08F1
c3201 → [3][2] → 0817		c3301 → 0817
c3202 → [5][4] → 0000		c3302 → 1F01
c3203 → [7][6] → 0000		c3303 → FA0A

So the response is FA0A1F01h, that in this case is negative so it's necessary to convert using the two's complement (NOT+1). After applying the conversion the number we found is 5F5E0FFh that converted in decimal result 9999999.

Pn817 = -99999999

3.2.2. - PARAMETER WRITE (Pn100: Speed loop gain = 100Hz)PROFIBUS-DP

- | | |
|--|---------------------------------|
| 1. Change the command code (1001b = 9h) | → [1] = 09 |
| 2. Parameter number (100hex) | → [2][3] = 01 00 |
| 3. Parameter data (100 = 64hex) | → [4][5][6][7] = 00 00 00 64 |
| 4. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c050 → [0][1] → 8009	When bit 050.08 turns On we have	c0350 → E009
c051 → [2][3] → 0100		c0351 → 0100
c052 → [4][5] → 0000		c0352 → 0000
c053 → [6][7] → 0064		c0353 → 0064

So we write

Pn100 = 100

In the same way that in read command, if the data is negative it should be write in two's complement (hexadecimal value inverter (NOT)+1)

DEVICE-NET

- | | |
|--|---------------------------------|
| 1. Change the command code (1001b = 9h) | → [1] = 09 |
| 2. Parameter number (100hex) | → [3][2] = 01 00 |
| 3. Parameter data (100 = 64hex) | → [7][6][5][4] = 00 00 00 64 |
| 4. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c3200 → [1][0] → 0980	When bit 3200.00 turns On we have	c3300 → 09F1
c3201 → [3][2] → 0100		c3301 → 0100
c3202 → [5][4] → 0064		c3302 → 0064
c3203 → [7][6] → 0000		c3303 → 0000

3.2.3. - SET ACTUAL POSITION (Define the actual position as -23456)PROFIBUS-DP

- | | |
|--|---------------------------------|
| 1. Change the command code (1010b = Ah) | → [1] = 0A |
| 2. Parameter number (none) | → [2][3] = 00 00 |
| 3. Parameter data (position) -23456 = FFFF6D7h | → [4][5][6][7] = FF FF F6 D7 |
| 4. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c050 → [0][1] → 800A	When bit 050.08 turns On we have	c0350 → E00A
c051 → [2][3] → 0000		c0351 → 0000
c052 → [4][5] → FFFF		c0352 → FFFF
c053 → [6][7] → F6D7		c0353 → F6D7

DEVICE-NET

- | | |
|--|---------------------------------|
| 1. Change the command code (1010b = Ah) | → [1] = 0A |
| 2. Parameter number (none) | → [3][2] = 00 00 |
| 3. Parameter data (position) -23456 = FFFF6D7h | → [7][6][5][4] = D7 F6 FF FF |
| 4. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c3200 → [1][0] → 0A80	When bit 3200.00 turns On we have	c3300 → 0AF1
c3201 → [3][2] → 0000		c3301 → 0000
c3202 → [5][4] → F6D7		c3302 → F6D7
c3203 → [7][6] → FFFF		c3303 → FFFF

3.2.4. - ALARM READ (Up to 4 alarms could be read)PROFIBUS-DP

- | | |
|--|---------------------------------|
| 1. Change the command code (1100b = Ch) | → [1] = 0C |
| 2. Parameter number (none) | → [2][3] = 00 00 |
| 3. Parameter data (none) | → [4][5][6][7] = 00 00 00 00 |
| 5. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c050 → [0][1] → 800C	When bit 050.08 turns On we have	c0350 → E10C
c051 → [2][3] → 0000		c0351 → 0000
c052 → [4][5] → 0000		c0352 → 9999
c053 → [6][7] → 0000		c0353 → 9972

When 99 is displayed it means that there is no alarm in the driver. 72 correspond to A.72 → Overload. In this example only the alarm 72 has been reproduced. If no alarm is detected the values will be 9999 and 9999.

DEVICE-NET

- | | |
|--|-----------------------------------|
| 1. Change the command code (1100b = Ch) | → [1] = 0C |
| 2. Parameter number (none) | → [3][2] = 00 00 |
| 3. Parameter data (none) | → [7][6][5][4] = 00 00 00 00 |
| 4. Activate the execution command bit C_STRT | → Change from [0] = 80 to [0] =81 |

It means:

c3200 → [1] [0] → 0C80	When bit 3200.00 turns On we have	c3300 → 0CF1
c3201 → [3] [2] → 0000		c3301 → 0000
c3202 → [5] [4] → 0000		c3302 → 9999
c3203 → [7] [6] → 0000		c3303 → 9999

3.2.5. - NSxx UNIT RESEST

This command reset the servodriver and the NSxx (it disconnects the power supply for a while). Before the reset command all the RAM parameters are write to the FLASH RAM.

PROFIBUS-DP

- | | |
|--|---------------------------------|
| 1. Change the command code (1110b = Eh) | → [1] = 0E |
| 2. Parameter number (none) | → [2][3] = 00 00 |
| 3. Parameter data (none) | → [4][5][6][7] = 00 00 00 00 |
| 4. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c050 → [0] [1] → 800E	When bit 050.08 turns ON the unit make the reset
c051 → [2] [3] → 0000	
c052 → [4] [5] → 0000	
c053 → [6] [7] → 0000	

DEVICE-NET


- | | |
|--|---------------------------------|
| 1. Change the command code (1110b = Eh) | → [1] = 0E |
| 2. Parameter number (none) | → [3][2] = 00 00 |
| 3. Parameter data (none) | → [7][6][5][4] = 00 00 00 00 |
| 4. Activate the execution command bit C_STRT | → Change from [0]= 80 to [0]=81 |

It means:

c3200 → [1] [0] → 0E80	When bit 3200.00 turns ON the unit make the reset
c3201 → [3] [2] → 0000	
c3202 → [5] [4] → 0000	
c3203 → [7] [6] → 0000	

3.3. - MOVEMENT COMMANDS

This kind of commands are used to make servo movements, the format of this messages is as follows.



- The command codes are this ones:
 - 0000** No operation
 - 0001** Simple positioning
 - 0010** External positioning
 - 0011** Positioning with notch signal output
 - 0100** Multi-speed positioning
- The **response type** define the kind of data that will be receive in the response data message:
 - 0000 Command position
 - 0001 Present position
 - 0010 Position error
 - 0011 Command speed (1000 command unit)
 - 0100 Present speed (1000 command unit)
 - 0101 Torque (%)
 - 1010 Station number
 - 1011 Point table number

• **Command bits**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
[2]	HOME	PTBL	STN	STEP	FEED	0	HOLD	CANCEL
[3]	0	0	0	0	0	0	DIR	INC

Where:

- CANCEL** Stops the positioning execution (deceleration to zero) and also reset the stored command position.
- HOLD** Stops the positioning execution (deceleration to zero) and wait for operation restart.
- FEED** While this bit is ON the motor run with the speed selected in command data or the feed speed depending of the selection in parameter Pn830, the rotation direction is fixed by status of DIR bit.
- STEP** This command executes a positioning with a STEP distance selected in the command data that correspond with parameters Pn844/./Pn847 and is make in the DIR direction
- STN** Station command that executes one positioning to the desired station in the DIR direction is possible to use incremental or absolute movements with the INC bit.
- PTBL** Execute a point table positioning.
- HOME** Execute an origin search command
- INC** This bit indicates if the coordinate system will be absolute or incremental when the STN and PTBL commands are used.
- DIR** This bit indicates the movement direction for FEED, STEP and STN commands.

Status bits

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
[2]	HOME_R	PTBL_R	STN_R	STEP_R	FEED_R	0	HOLD_R	PRGS
[3]	POT	NOT	INPOS	NEAR	HOME_P		DIR_R	INC_R

Where:

- PRGS** Flag that indicates operation in progress (active during a positioning)
- HOLD_R** Flag that turns on when the HOLD command is received in the NSxx board.
- FEED_R** Flag that turns on when the FEED command has been received, but it doesn't indicate that a movement is in process.
- STEP_R** Flag that turns on when STEP command is active and turns OFF when the command has finished.
- STN_R** Flag that turns on when STN command is active and turns OFF when the command has finished.
- PTBL_R** Flag that turns on when PTBL command is active and turns OFF when the command has finished.
- HOME_R** Flag that turns on when HOME command is active and turns OFF when the command has finished..
- INC_R** Flag that indicates that positionings are defined to work in absolute (0) or Incremental (1) coordinates.
- DIR_R** Flag that shows the rotation direction: (0) Forward / (1) Reverse.
- HOME_P** Flag that turns on when the servomotor is in the origin (range Pn806).
- NEAR** Flag that turns on when servomotor is close to the target position (range Pn852).
- INPOS** Flag that turns on when the servomotor has arrived to the target position /(INPOSITION) (range Pn850).
- NOT** Shows the negative overtravel limit input status NOT (CN1)
- POT** Shows the positive overtravel limit input status POT (CN1)


3.3.1 HOME COMMAND (ORIGIN SEARCH)

This function uses external signal to define a fix point (hardware) as origin, which will be used as a reference for any positioning.

- There are 4 available methods in Pn800:
- 0 → 3-step deceleration using DEC signal (CN1-41) and Z phase
 - 1 → 2-step deceleration using ZERO signals (CN1-45)
 - 2 → 3-step deceleration using DEC (CN1-41) and ZERO (CN1-45)
 - 3 → 2-step deceleration using Z encoder phase

In parameter Pn801.0 is possible to define the origin search direction, in the Pn801.1 the activation level for DEC signal and in the Pn801.2 if the Zero signal will work in rising or falling edge.

Pn800 = 0 (Using the DEC signal and the Z encoder phase)



When the HOME command turns on, the origin search starts in the selected direction (Pn801.0) at the origin search speed Pn802. When the rising edge of /DEC signal (CN1-41) comes, the speed decrease to the origin approach speed Pn803 and in the first pulse of Z phase after the falling edge of the /DEC signal the servomotor moves according the selected position in Pn805 (Zero point return final travel distance) at the zero point return creep speed Pn804.

The acceleration and deceleration ramp are defined in parameter Pn80A.

Also two flags are available for monitor the operation status:

HOME_R that remains active from the command start until the origin has been established.

HOME_P that turns on when servomotor arrives to the origin, with a range defined in Pn806.

ORIGIN SEARCH PARAMETERS

Pn800	Zero point return mode
Pn801*	Bit 0: Origin search direction: Fwd(0) Rev(1)
	Bit 1: Origin proximity level/DEC
	Bit 2: Zero point signal level/ZERO
	Bit 3-15: -
Pn802	Zero point return speed

Pn803	Zero point return approach speed
Pn804	Zero point return creep speed
Pn805	Zero point return final travel distance
Pn806	Zero point output width
Pn809	Zero point offset
Pn80A	Zero point Accel/decel time

This is the more complex function and corresponds to the 0 value of Pn800. With the other values 1, 2 and 3 we'll have this behaviour:

-(1) Only the ZERO signal (CN1-45), so the operation will start at the approach origin speed and in the rising edge of Zero signal the final positioning distance will be done.

- (2) /DEC and ZERO signal. Is the same case that in mode (0) but the signal that is used for the final positioning is the ZERO (CN1-45) instead the Z phase pulse.

-(3) Only Z phase, the movement will start at the origin approach speed and when the first rising edge of Z phase arrives the final distance positioning will be executed.

Command execution example:

1. - Turn On the software emergency stop bit (ESTP)

PROFIBUS-DP
 c050 → [0] [1] → 1000
 c051 → [2] [3] → 0000
 c052 → [4] [5] → 0000
 c053 → [6] [7] → 0000

c3200 → [1][0] → 0010
 c3201 → [3][2] → 0000
 c3202 → [5][4] → 0000
 c3203 → [7][6] → 0000
 DEVICE-NET

2. - Turn on the servo RUN signal (SVON)

PROFIBUS-DP
 c050 → [0] [1] → 1200
 c051 → [2] [3] → 0000
 c052 → [4] [5] → 0000
 c053 → [6] [7] → 0000

c3200 → [1][0] → 0012
 c3201 → [3][2] → 0000
 c3202 → [5][4] → 0000
 c3203 → [7][6] → 0000
 DEVICE-NET

3. - Turn on the origin search bit (HOME) with the selected response type (ex: present speed)

PROFIBUS-DP
 c050 → [0] [1] → 1240
 c051 → [2] [3] → 8000
 c052 → [4] [5] → 0000
 c053 → [6] [7] → 0000

c0350 → [0][1] → 7240
 c0351 → [2][3] → 8100
 c0352 → [4][5] → xxxx
 c0353 → [6][7] → xxxx

Where xxxxxx is the response value.

DEVICE-NET

c3200 → [1] [0] → 4012
 c3201 → [3] [2] → 0080
 c3202 → [5] [4] → 0000
 c3203 → [7] [6] → 0000
 c3300 → [1][0] → 4062
 c3301 → [3][2] → 0081
 c3302 → [5][4] → xxxx
 c3303 → [7][6] → xxxx

Where xxxxxx is the response value.

3.3.2 FEED COMMAND

While the FEED command is active the motor will run indefinitely in the direction selected in DIR bit and at the speed selected in parameter Pn831 (Constant feed speed)

The acceleration and deceleration ramps are defined by parameters Pn829, Pn832 and Pn843

The speed could be changed by the override value if the FEED bit remains activated.

Also is possible to define the speed depending on Pn830 configuration:

- Pn830 = 1 → Parameter data is take as speed for feeding in 1000 reference units/min.
- Pn830 = 0 → Parameter data is take as override (0% to 200% of the FEED speed selected in Pn831), but never up to the maximum speed Pn843

The parameters used are these ones:

Pn829	Filter selection acc/dec(-, exp., exp. bias., average)
Pn830	Bit 0: Override (0), direct speed in command message (1)
Pn831	Constant FEED speed
Pn832	Acceleration time for constant FEED
Pn833	Deceleration time for constant FEED
Pn834	Switch speed for constant feed second Acc/dec

Pn835	Acc/dec time for constant feed second Acc/dec
Pn836	Acc/dec type for constant feed(-,single,double,asy)
Pn840	Time constant for exponential Acc/dec
Pn841	Bias speed for exponential Acc/dec
Pn842	Time constant of travelling average
Pn843	Maximum feed speed

Command execution example

1. - Turn on the software emergency stop bit (ESTP)

PROFIBUS-DP
 c050 → [0] [1] → 1000
 c051 → [2] [3] → 0000
 c052 → [4] [5] → 0000
 c053 → [6] [7] → 0000

c3200 → [1][0] → 0010
 c3201 → [3][2] → 0000
 c3202 → [5][4] → 0000
 c3203 → [7][6] → 0000

DEVICE-NET

2. - Turn on the servomotor RUN bit (SVON)

PROFIBUS-DP
 c050 → [0] [1] → 1200
 c051 → [2] [3] → 0000
 c052 → [4] [5] → 0000
 c053 → [6] [7] → 0000

c3200 → [1][0] → 0012
 c3201 → [3][2] → 0000
 c3202 → [5][4] → 0000
 c3203 → [7][6] → 0000

DEVICE-NET

3. - Select the rotation direction with DIR
 Byte [3] = 0000 0000 forward
 Byte [3] = 0000 0010 reverse.

Select the speed
 [4][5][6][7] (PROFIBUS-DP)
 [7][6][5][4] (DEVICE-NET)

Always in hexadecimal and depending of Pn830 value.
 Select the response type (ex: present speed [1] = 0100 000)

If Pn830 =1 (x1000 units/min), Pn810 = 1 y Pn811 = 1, we have a 2048ppr encoder and the desired speed is 2000 rpm, we should select:

1 rev = 2048p x 4 = 8192p → 2000 rev = 8192 x 2000 = 16384000. Speed = 16384 (x1000/min) = 4000h

PROFIBUS-DP
 c050 → [0] [1] → 1200
 c051 → [2] [3] → 0000
 c052 → [4] [5] → 0000
 c053 → [6] [7] → 4000

c3200 → [1][0] → 0012
 c3201 → [3][2] → 0000
 c3202 → [5][4] → 4000
 c3203 → [7][6] → 0000

DEVICE-NET

If Pn830 = 0 (override over Pn831), Pn831 = 24000 (x1000/min) and the desired speed is 2000rpm:

$2000\text{rpm} = 16384000 / 24000000 = 0.682 \rightarrow 68\% = 44\text{h} \rightarrow [4][5][6][7] = 0000\ 0044$ en PROFIBUS

$[7][6][5][4] = 0044\ 0000$ en DEVICE-NET

PROFIBUS-DP	c050 \rightarrow [0] [1] \rightarrow 1200	c3200 \rightarrow [1][0] \rightarrow 0012	DEVICE-NET
	c051 \rightarrow [2] [3] \rightarrow 0000	c3201 \rightarrow [3][2] \rightarrow 0000	
	c052 \rightarrow [4] [5] \rightarrow 0000	c3202 \rightarrow [5][4] \rightarrow 0044	
	c053 \rightarrow [6] [7] \rightarrow 0044	c3203 \rightarrow [7][6] \rightarrow 0000	

4. - Turn on the FEED bit

Byte [2] = 0000 1000 to execute the command.

<u>PROFIBUS-DP</u>	c050 \rightarrow [0] [1] \rightarrow 1240	c0350 \rightarrow [0][1] \rightarrow 6240
	c051 \rightarrow [2] [3] \rightarrow 0800	c0351 \rightarrow [2][3] \rightarrow 0900
	c052 \rightarrow [4] [5] \rightarrow 0000	c0352 \rightarrow [4][5] \rightarrow xxxx
	c053 \rightarrow [6] [7] \rightarrow 4000	c0353 \rightarrow [6][7] \rightarrow xxxx

Where xxxxxxx is the response value.

<u>DEVICE-NET</u>	c3200 \rightarrow [1] [0] \rightarrow 4012	c3300 \rightarrow [1][0] \rightarrow 4062
	c3201 \rightarrow [3] [2] \rightarrow 0008	c3301 \rightarrow [3][2] \rightarrow 0009
	c3202 \rightarrow [5] [4] \rightarrow 0000	c3302 \rightarrow [5][4] \rightarrow xxxx
	c3203 \rightarrow [7] [6] \rightarrow 0000	c3303 \rightarrow [7][6] \rightarrow xxxx

Where xxxxxxx is the response value.

3.3.3 STEP COMMAND

While the STEP command bit is ON, the motor will run in the desired direction DIR at the specific speed Pn821 during the step distance specify by Pn844 (STEP1), Pn845 (STEP2), Pn846 (STEP3) or Pn847 (STEP4).

The acceleration and deceleration ramps are defined in parameters Pn822 to Pn829 and Pn840 to Pn843

It's not possible to change the speed that is fixed in parameter Pn821

The related parameters are these ones:

Pn821	Feed speed for positioning
Pn822	Acceleration time for positioning
Pn823	Deceleration time for positioning
Pn824	Switch speed for second Acc/dec for positioning
Pn825	Acc/dec time for second Acc/dec for positioning
Pn826	Acc/dec type for positioning
Pn829	Filter selection
Pn840	Time constant for exponential Acc/dec

Pn841	Bias speed for exponential Acc/dec
Pn842	Time constant of travelling average
Pn843	Maximum feed speed
Pn844	Step distance 1
Pn845	Step distance 2
Pn846	Step distance 3
Pn847	Step distance 4

Command execution example:

1. - Turn on the software emergency stop (ESTP)

PROFIBUS-DP	c050 → [0] [1] → 1000	c3200 → [1][0] → 0010	
	c051 → [2] [3] → 0000	c3201 → [3][2] → 0000	
	c052 → [4] [5] → 0000	c3202 → [5][4] → 0000	DEVICE-NET
	c053 → [6] [7] → 0000	c3203 → [7][6] → 0000	

2. - Turn on the servomotor RUN bit (SVON)

PROFIBUS-DP	c050 → [0] [1] → 1200	c3200 → [1][0] → 0012	
	c051 → [2] [3] → 0000	c3201 → [3][2] → 0000	
	c052 → [4] [5] → 0000	c3202 → [5][4] → 0000	DEVICE-NET
	c053 → [6] [7] → 0000	c3203 → [7][6] → 0000	

3. - Select the motor rotation direction DIR

Byte [3] = 0000 0000 forward, [3] = 0000 0010 reverse.

Select the step distance

[4][5][6][7] 0000 0000 (STEP1) to 0000 0003 (STEP4) PROFIBUS-DP

[7][6][5][4] 0000 0000 (STEP1) to 0000 0003 (STEP4) DEVICE-NET

Select the response type (ex.: present position [1] = 0001 000)

PROFIBUS-DP	c050 → [0] [1] → 1210	c3200 → [1][0] → 1012	
	c051 → [2] [3] → 0000	c3201 → [3][2] → 0000	
	c052 → [4] [5] → 0000	c3202 → [5][4] → 0002	DEVICE-NET
	c053 → [6] [7] → 0002	c3203 → [7][6] → 0000	

4. - Turn on the STEP bit byte [2] = 0001 0000 to execute the command

<u>PROFIBUS-DP</u>	c050 → [0] [1] → 1210	c0350 → [0][1] → 6210
	c051 → [2] [3] → 1000	c0351 → [2][3] → 1100
	c052 → [4] [5] → 0000	c0352 → [4][5] → xxxx
	c053 → [6] [7] → 0002	c0353 → [6][7] → xxxx

Where xxxxxxx is the presernt position.

<u>DEVICE-NET</u>	c3200 → [1] [0] → 1012	c3300 → [1][0] → 1062
	c3201 → [3] [2] → 0010	c3301 → [3][2] → 3010
	c3202 → [5] [4] → 0002	c3302 → [5][4] → xxxx
	c3203 → [7] [6] → 0000	c3303 → [7][6] → xxxx

Where xxxxxxx is the presernt position

4. - Turn on the PTBL bit byte [2] = 0100 0000 to execute the command

PROFIBUS-DP

c050 → [0] [1] → 1210

c051 → [2] [3] → 4003

c052 → [4] [5] → 0000

c053 → [6] [7] → 001B

c0350 → [0][1] → 6210

c0351 → [2][3] → 4103

c0352 → [4][5] → xxxx

c0353 → [6][7] → xxxx

Where xxxxxxx is the present position.

DEVICE-NET

c3200 → [1] [0] → 1012

c3201 → [3] [2] → 0340

c3202 → [5] [4] → 001B

c3203 → [7] [6] → 0000

c3300 → [1][0] → 1062

c3301 → [3][2] → 0341

c3302 → [5][4] → xxxx

c3303 → [7][6] → xxxx

Where xxxxxxx is the present position

3.3.5 SIMPLE POSITIONING

This command is used to make movements to a target position send by communications. To use it is necessary to write the command 0001 in byte [1] so it should be executed by the C_STRT bit. The coordinate type could be select by the INC bit.

The speed for this positioning is fixed to parameter Pn821 (Feed speed for positioning).

Acceleration and deceleration ramps are selected by parameter Pn822 to Pn826, Pn829, and Pn840 to Pn843.

The related parameters are these ones:

Pn821	Feed speed for positioning
Pn822	Acceleration time for positioning
Pn823	Deceleration time for positioning
Pn824	Switch speed for 2 nd Acc/dec
Pn825	Acc/dec time for 2 nd Acc/dec for positioning
Pn826	Acc/dec type for positioning

Pn829	Filter selection
Pn840	Time constant for exponential Acc/dec
Pn841	Bias speed for exponential Acc/dec
Pn842	Time constant of travelling average
Pn843	Maximum feed speed

Execution command example:

1. - Turn on the software emergency stop bit (ESTP)

<u>PROFIBUS-DP</u>	c050 → [0] [1] → 1000
<u>DEVICE-NET</u>	c3200 → [1] [0] → 0010

2. - Turn on the servomotor RUN bit (SVON)

<u>PROFIBUS-DP</u>	c050 → [0] [1] → 1200
<u>DEVICE-NET</u>	c3200 → [1][0] → 0012

- 3.-Select the SIMPLE POSITIONING command ([1] = xxxx 0001)
 Select the rotation direction DIR bit
 Byte [3] = 0000 0000 forward, [3] = 0000 0010 reverse.

Select the coordinate system INC bit
 Byte [3] = 0000 0000 ABS [3] = 0000 0001 INC

Select the response type (ex: present position [1] = 0001 000)
 Select the final position in hexadecimal
 [4][5][6][7] PROFIBUS-DP
 [7][6][5][4] DEVICE-NET
 Example -10000 = FFFF D8F0;

	c050 → [0] [1] → 1211		c3200 → [1][0] → 1112
PROFIBUS-DP	c051 → [2] [3] → 0001	INC	c3201 → [3][2] → 0100
	c052 → [4] [5] → FFFF		c3202 → [5][4] → D8F0
	c053 → [6] [7] → D8F0	-10000 units	c3203 → [7][6] → FFFF
			DEVICE-NET

4. - Turn on the C_STRT start bit on byte [0] (change from [0] = 12 to [0] = 13) to execute the command

<u>PROFIBUS-DP</u>	c050 → [0] [1] → 1211	When bit c0050.8 turns on	c0350 → [0][1] → 7311
	c051 → [2] [3] → 0001		c0351 → [2][3] → 0003
	c052 → [4] [5] → FFFF		c0352 → [4][5] → xxxx
	c053 → [6] [7] → D8F0		c0353 → [6][7] → xxxx

Where xxxxxxxx is the present posititon.


<u>DEVICE-NET</u>	c3200 → [1] [0] → 1112	When bit c3200.00 turns on	c3300 → [1][0] → 1162
	c3201 → [3] [2] → 0100		c3301 → [3][2] → 3100
	c3202 → [5] [4] → D8F0		c3302 → [5][4] → xxxx
	c3203 → [7] [6] → FFFF		c3303 → [7][6] → xxxx

Where xxxxxxxx is the present position

3.3.6 EXTERNAL POSITIONING

This command executes a movement to the desired position in the command parameters at the selected speed (Pn821). If the EXTP (CN1-44) turns on during the positioning the motor will decelerate to the approach speed (Pn854) and it will move the travel positioning distance (Pn855) from the External positioning signal.

The 0010 command in byte [1] should be used and the C_STRT bit it's needed to start the movement. Also the coordinate type (ABS or INC) could be defined in INC byte [3].



The acceleration and deceleration ramps are defined in parameters Pn822 to Pn826, Pn829, and Pn840 to Pn843.

The related parameters are these ones:

Pn821	Feed speed for positioning
Pn822	Acceleration time for positioning
Pn823	Deceleration time for positioning
Pn824	Switch speed for 2 nd Acc/dec for positioning
Pn825	Acc/dec time for 2 nd Acc/dec for positioning
Pn826	Acc/dec type for positioning
Pn829	Filter selection

Pn840	Time constant for exponential Acc/dec
Pn841	Bias speed for exponential Acc/dec
Pn842	Time constant of travelling average
Pn843	Maximum feed speed
Pn854	Approach speed for external positioning
Pn855	Travel distance for external positioning

Command execution example

1. - Turn on the software emergency stop bit (ESTP)

PROFIBUS-DP c050 → [0] [1] → 1000
 DEVICE-NET c3200 → [1] [0] → 0010

2. - Turn on the servomotor RUN bit (SVON)

PROFIBUS-DP c050 → [0] [1] → 1200
 DEVICE-NET c3200 → [1][0] → 0012

3. - Select the external positioning code ([1] = xxxx 0010)
 Select the coordinate type using the INC bit ([3] = 0000 0000 ABS, [3] = 0000 0001 INC)
 Select the response type (ex.: present position [1] = 0001 000)
 Select the target position in hex [4] [5] [6] [7] (PROFIBUS-DP) or [7] [6] [5] [4] (DEVICE-NET).

Ex 245670 = 0003 BFA6;

PROFIBUS-DP	c050 → [0] [1] → 1212		c3200 → [1][0] → 1212	
	c051 → [2] [3] → 0001	INC	c3201 → [3][2] → 0100	DEVICE-NET
	c052 → [4] [5] → 0003		c3202 → [5][4] → BFA6	
	c053 → [6] [7] → BFA6	245670 unidades	c3203 → [7][6] → 0003	

4. - Turn on the C_STRT bit byte [0] (go from [0] = 12 to [0] = 13) to execute the command

PROFIBUS-DP	c050 → [0] [1] → 1312	When c0050.8 turns on	c0350 → [0][1] → 7312
	c051 → [2] [3] → 0001		c0351 → [2][3] → 0001
	c052 → [4] [5] → 0003		c0352 → [4][5] → xxxx
	c053 → [6] [7] → BFA6		c0353 → [6][7] → xxxx

where xxxxxx is the present position.

DEVICE-NET	c3200 → [1] [0] → 1213	When c3200.00 turn on	c3300 → [1][0] → 1263
	c3201 → [3] [2] → 0100		c3301 → [3][2] → 3100
	c3202 → [5] [4] → BFA6		c3302 → [5][4] → xxxx
	c3203 → [7] [6] → 0003		c3303 → [7][6] → xxxx

Where xxxxxx is the present position.

3.3.7 POSITIONING WITH NOTCH SIGNALS


This command executes one movement to the specified point and the preset speed (Pn821) like in a simple positioning. The only difference is referred with the present position, if the actual position is between some levels defined in parameters Pn892 and Pn893 for Notch1 (CN4-12/13) or Pn894 and Pn895 for Notch2 (CN-10/20) this output will turn on. The command code is 0011 in byte [1] and movement starts with the C_STRT bit. The coordinate type (ABS or INC) is defined in INC byte [3].

The acceleration and deceleration ramps are defined in parameters Pn822 to Pn826, Pn829, and Pn840 to Pn843.

The related parameters are these ones:

Pn821	Feed speed for positioning
Pn822	Acceleration time for positioning
Pn823	Deceleration time for positioning
Pn824	Switch speed for 2 nd Acc/dec for positioning
Pn825	Acc/dec time for 2 nd Acc/dec for positioning
Pn826	Acc/dec type for positioning
Pn829	Filter selection
Pn840	Time constant for exponential Acc/dec
Pn841	Bias speed for exponential Acc/dec
Pn842	Time constant of travelling average
Pn843	Maximum feed speed

PARAMETERS RELATED WITH NOTCH	
Pn890	Notch signal output position setting
Pn891	Bit 0: Enable the NOTCH1 output Bit 1: Disable the NOTCH2 output
Pn892	Notch 1 lower limit
Pn893	Notch 1 upper limit
Pn894	Notch 2 lower limit
Pn895	Notch 2 upper limit



Command execution example

1. - Turn on the software emergency stop (ESTP)

PROFIBUS-DP c050 → [0] [1] → 1000
 DEVICE-NET c3200 → [1] [0] → 0010

2. - Turn on the servomotor RUN bit (SVON)

PROFIBUS-DP c050 → [0] [1] → 1200
 DEVICE-NET c3200 → [1][0] → 0012

3. - Select the positioning with notch signal outputs command code ([1] = xxxx 0011)
 Select the coordinate type using the INC bit ([3] = 0000 0000 ABS, [3] = 0000 0001 INC)
 Select the response type (ex.: present position [1] = 0001 000)
 Select the target position in hex [4] [5] [6] [7] (PROFIBUS-DP) or [7] [6] [5] [4] (DEVICE-NET).
 Example 200000 = 0003 0D40;

PROFIBUS-DP	c050 → [0] [1] → 1213		c3200 → [1][0] → 1212	
	c051 → [2] [3] → 0001	INC	c3201 → [3][2] → 0100	DEVICE-NET
	c052 → [4] [5] → 0003		c3202 → [5][4] → BFA6	
	c053 → [6] [7] → 0D40	200000 units	c3203 → [7][6] → 0003	

4. - Turn on the C_STRT bit byte [0] (change from [0] = 12 to [0] = 13) to execute the command

PROFIBUS-DP c050 → [0] [1] → 1313 When c0050.8 turn on c0350 → [0][1] → 7313
 c051 → [2] [3] → 0001 c0351 → [2][3] → 0001

c052 → [4] [5] → 0003
 c053 → [6] [7] → 0D40

c0352 → [4][5] → xxxx
 c0353 → [6][7] → xxxx

where xxxxxxx is the present position.

<u>DEVICE-NET</u>	c3200 → [1] [0] → 1313	when c3200.00 turns on	c3300 → [1][0] → 1363
	c3201 → [3] [2] → 0100		c3301 → [3][2] → 3100
	c3202 → [5] [4] → 0D40		c3302 → [5][4] → xxxx
	c3203 → [7] [6] → 0003		c3303 → [7][6] → xxxx

Where xxxxxxx is the present position

3.3.8 MULTI-SPEED POSITIONING

This command executes a positioning to the target point with an initial speed defined in Pn861 just like in simple positioning. But if during the positioning the present position goes trough a speed change point (Pn863 to Pn872) the speed will change to the selected speed (Pn873 to Pn882) if the behaviour has been enable (Pn861).

The command code is the 0100 in byte [1] and is executed by C_STRT bit. The coordinate type (ABS or INC) is defined in INC byte [3].


The acceleration and deceleration ramps are defined in parameters Pn822 to Pn826, Pn829, and Pn840 to Pn843.

The related parameters are these ones:

Pn822	Acceleration time for positioning
Pn823	Deceleration time for positioning
Pn824	Switch speed for 2 nd Acc/dec for positioning
Pn825	Acc/dec time for 2 nd Acc/dec for positioning
Pn826	Acc/dec type for positioning
Pn829	Filter selection
Pn840	Time constant for exponential Acc/dec
Pn841	Bias speed for exponential Acc/dec
Pn842	Time constant of travelling average
Pn843	Maximum feed speed

MULTI-SPEED PARAMETERS	
Pn861	Number of points for speed switching
Pn862	Initial feed speed for positioning
Pn863	Speed switching position 1
Pn864	Speed switching position 2
Pn865	Speed switching position 3
...	...
Pn872	Speed switching position 16
Pn873	Switching speed 1
Pn874	Switching speed 2
Pn875	Switching speed 3
...	...
Pn882	Switching speed 16

Example:



1. - Parameters that should be programmed are these ones:

- Pn861 = Number of points for speed switching = 4
- Pn862 = Initial feed speed for multi-speed positioning = 15000
- Pn863 = Speed switching position 1 = 10000
- Pn864 = Speed switching position 2 = 25000
- Pn865 = Speed switching position 3 = 35000
- Pn866 = Speed switching position 4 = 40000
- Pn873 = Switching speed 1 = 10000
- Pn874 = Switching speed 2 = 24000
- Pn875 = Switching speed 3 = 17500
- Pn876 = Switching speed 4 = 1000

2. - Turn on the software emergency stop (ESTP)

PROFIBUS-DP c050 → [0] [1] → 1000
DEVICE-NET c3200 → [1] [0] → 0010

3. - Turn on the servomotor RUN bit (SVON)

PROFIBUS-DP c050 → [0] [1] → 1200
DEVICE-NET c3200 → [1][0] → 0012

4. - Select the command code for Multi-speed positioning ([1] = xxxx 0100)
 Select the coordinate type using the INC bit ([3] = 0000 0000 ABS, [3] = 0000 0001 INC)
 Select the response type (ex.: present position [1] = 0001 000)
 Select the target position in hex [4] [5] [6] [7] (PROFIBUS-DP) or [7] [6] [5] [4] (DEVICE-NET).
 Example 55000 = 0000 D6D8;

	c050 → [0] [1] → 1214		c3200 → [1][0] → 1412	
	c051 → [2] [3] → 0001	INC	c3201 → [3][2] → 0100	
<u>PROFIBUS-DP</u>	c052 → [4] [5] → 0000		c3202 → [5][4] → D6D8	<u>DEVICE-NET</u>
	c053 → [6] [7] → D6D8	55000 units	c3203 → [7][6] → 0000	

5. - Turn on the C_STRT bit byte [0] (change from [0] = 12 to [0] = 13) to execute the command

<u>PROFIBUS-DP</u>	c050 → [0] [1] → 1314	When c0050.8 turns on	c0350 → [0][1] → 7314
	c051 → [2] [3] → 0001		c0351 → [2][3] → 0001
	c052 → [4] [5] → 0000		c0352 → [4][5] → xxxx
	c053 → [6] [7] → D6D8		c0353 → [6][7] → xxxx

Where xxxxxxx is the present position.


<u>DEVICE-NET</u>	c3200 → [1] [0] → 1413	When c3200.00 turns on	c3300 → [1][0] → 1363
	c3201 → [3] [2] → 0100		c3301 → [3][2] → 3100
	c3202 → [5] [4] → D6D8		c3302 → [5][4] → xxxx
	c3203 → [7] [6] → 0000		c3303 → [7][6] → xxxx

Where xxxxxxx is the present position

4- SOFTWARE (NSxxxSETUPTOOLS)


4.1. - INTRODUCTION

When the software starts the connection dialogue will appear. Here is possible to select the communication port where the NS500/300 is connected. The communication parameters are fixed. Also is possible to access this one from the FILE/CONNECT TO NSxxx menu.




When the communication has started is possible to see some servodriver status flags like READY, SERVO ON/OFF and MAIN POWER status in the bottom of the screen.

FILE MENU:




On this menu we have several options like “CONNECT TO NSxxx”. Also is possible to save parameters or point tables from a file to the NS “LOAD TO NSxxx. Also is possible to store the NS parameters or tables into a file “SAVE FROM NSxxx”, and also is possible to verify the content. In the last option is possible to configure the units that should be used in the software but this is only for monitor issues, so really is not changing any parameter in the NS

MONITOR:



From this option is possible to monitor the internal status flags from the NS board “MONITOR STATUS”, the external inputs and outputs status of the servodriver and option board “INPUT SIGNAL / OUTPUT SIGNAL”. Also is possible to monitor the actual position and the error counter “CURRENT POSITION”, the active alarms “ALARM” and the alarm history “ALARM HISTORY” or clear this history “CLEAR”

SYSTEM:




These option present two different functions:

READ ID: Reads the firmware version and model of the servodriver, NSxxx and servomotor.


RESET MODULE: Store all the work memory RAM into the EEPROM, so this option is needed to make some of the changes active and to save the entire configuration. After the reset is made the NSxxx is initialised.

PARAMETER




Here is possible to see or edit the module and servodriver parameter list 'OPTION PARAMETER LIST' or 'SERVO PARAMETER LIST' for each case.

POINT TABLE




With this option is possible to see or edit all the point table parameters Pn900 to Pn931 for positions Pn980 to Pn9B1 for speeds.

SIGNAL



Here is possible to start the servodriver activating the RUN (SERVO ON/OFF) bit. Also is possible to realise the brake (BRAKE ON/OFF)

OPERATE



Here is possible to execute the different movements that this board allows. Several options are available:


JOG: Command that allows a continuous movement at the desired speed where also is possible to select the rotation direction FORWARD ó REVERSE. While the key is pressed the movement continues.

STEP: Command that execute a positioning with the speed and target distance fixed by parameters. Also is possible to select the rotation direction by FORWARD or REVERSE.

POSITIONING: Command that moves to the desired point at selected speed where also is possible to select between

ABS or INC coordinates.


POINT TABLE POSITIONING: Command that executes a movement stored in one of the 50 positions table.



MULTI-SPEED POSITIONING: Command that executes a positioning movement to a fixed point where speed change depending of the present position. Both position and speeds are fixed by parameters.

EXTERNAL POSITIONING: Command to execute a positioning to a selected distance and speed in INC or ABS coordinates. But if during positioning the external signal turns on the actual movement will stop following another movement store in parameters will be performed.

HOMING OPERATION: Command that executes an origin search operation.



ZONE-SIGNAL OUTPUT POSITIONING: Command that executes a positioning with a specified speed and target position. The NOTCH signal will activate if the actual position is inside some position zones.


STATION POSITIONING: Command that executes a movement to different stations in which the total distance has been divided. It's possible to use this one in INC or ABS coordinates.

5- FIELD BUS CONFIGURATION

5.1- PROFIBUS DP CONFIGURATION

Next steps are needed to configure the Profibus DP bus:

- 1- Master C200HW-PRM21 and slaves (in this case NS500) installation and wiring.
- 2- Master configuration with the SYCOND software




With this software is possible to supply information about the slaves connected to the bus and also configure some basic parameters. It's not possible to activate the C200HW-PRM21 master without this software.

The C200HW-PRM21 master has a special port dedicated to the configuration, and this port is the one that should be used to program the unit. The cable configuration is this one:


PC	C200HW-PRM21
2	2
3	3
5	9

- These are the step to follow: - Add the hardware components of the system (master / slaves) and define the bus configuration.
- Define the slave data allocation into the unit internal buffers.
 - Define the communication parameters.
 - Transfer the configuration to the Profibus master C200HW-PRM21.


First point is add the master devices



Select the bus slaves




Each Profibus device has its own .GSD file that should be supplied with the device. It's necessary to copy this file into the "PATH..." directory selected in the "Settings" menu, because in any other case the device will not be listed by the software.




The GSD file for the NS500 is the: "YASK0508.gsd"

When the bus has been created it's necessary to define the master and slaves (in case that available) parameters like the Profibus number.


In the master only is necessary to select the unit number and the autoaddressing function. In this case no modification is needed and only it's important check the unit number in the master and slave.




To check the address assignment the “Address Table...” function should be used in the “View” menu.




Before the download of the configuration into the master the bus communication speed should be configured in “Bus parameter” and selecting the communication port in “Device assignment”.



Last point is transfer the configuration to the master



Once the configuration has been transmitted is possible to use the debug option to check that all is working and there is no problem in any slave.



- 3- **Start the bus communication.** To do it only is necessary to turn on the bit 0 in the 1st channel of the special unit area in the PLC:

- C200Halpha $(100 + (10 \times N^{\circ} \text{unidad})).00$ Ex: Unit N^o = 0 → 100.00
 - CS1 $(2000 + (10 \times N^{\circ} \text{unidad})).00$ Ex: Unit N^o = 0 → 2000.00

- 4- **Channel assignment.** Each slave has a different number of I/O bytes depending of the slave type. For the NS500 we have 8 bytes for the input and 8 bytes for the outputs, it means that 4 channels (word) for inputs and 4 for outputs are needed in the master.

The addresses are assigned from channel c0050 (PLC → NSxxx) and from c0350 (NSxxx → PLC)

For this example only one slave is used and the assigned channels are c0050/c0051/c0052/c0053 for outputs and c0350/c0351/c0352/c0353 as inputs.

5.2- DEVICE-NET CONFIGURATION

The steps that should be following to configure the device-net bus are these ones:

1. Master C200HW-DRM21-V1 or CS1W-DRM21 and slaves (in this case NS300) installation and wiring.
2. Master configuration with the Device-Net software configurator.



With this software is possible to supply information to the master about the slaves and some basic parameters of the bus.


The CS1W-DRM21 master should be programmed through the PLC communication port but for the C200HW-DRM21 the 3G8E2-DRM21 (PCMCIA to Device-Net) adaptor is needed. The cable for the CS1W-DRM21 has the same configuration than the programming cable for the PLC.

PC	CS1W-DRM21
2	2
3	3
5	9


Follow these steps:

- Add all the devices that bus should contain (master / slave) and define the bus configuration.
- Define the slave data allocation into the internal buffers of the unit.
- Define the communication parameters.
- Download the configuration into the Device-net master.

First point is add the master and slaves devices





Each device has its own .EDS file that should be supply with the device. This file should be added to the software by the “INSTALL” option in the “EDS FILE” menu and selecting the desired EDS file in the corresponding folder.




The EDS file for the NS300 is the: “NS300.EDS”

When the bus has been create is time to define the unit numbers for each bus device according to the hardware selection (Rotary switches in the front side of slave and master).

Next step is reference each slave with a master, to do it is possible to drag the slave to the master.




To check the assignation in the master only is necessary to double-click over the master and this window should appear:




Where is possible to check the input and output interface channels between the master and the slaves.

In this case the first slave #1 (NS300) occupies:
 -4 output channels (c3200, c3201, c3202 and c3203)
 -4 input channels (c3300, c3301, c3302 and c3303)

When the bus has been set-up it's time to communicate with the master. To do it use the “connect” option in the “Network” menu, here is possible to select the PLC port configuration.



Final step is download the configuration, use the left mouse button over the master and a new window will appear, use the “Download” option in the “parameter” menu to start the transmission.



When all the information has been transferred the bus will start the communication, if there is no error. The master checks that the entire configuration is Ok and that all slaves are working properly.