

Cat. No.  
ABBO 0017

**Diffuse Reflective Sensor  
E3NT-L**

**Photoelectric Sensor**

**OPERATION MANUAL**

**OMRON**



# TABLE OF CONTENTS

## SECTION 1

<b>Important Precautions</b> .....	<b>5</b>
1-1 Using the operating instructions .....	6
1-2 Use in accordance with the intended purpose .....	6
1-3 Use that is not in accordance with the intended purpose .....	6
1-4 Electromagnetic compatibility (EMC) .....	6
1-5 Warranty and liability .....	7
1-6 Key to symbols .....	7
1-7 Abbreviations .....	7

## SECTION 2

<b>Safety Notes</b> .....	<b>9</b>
2-1 Safety notes .....	10

## SECTION 3

<b>Specification</b> .....	<b>11</b>
3-1 Diffuse reflective sensor .....	12
3-2 Optical data link E3NT-AL232 (order separately) .....	17
3-3 Dimensions .....	18

## SECTION 4

<b>Function</b> .....	<b>23</b>
4-1 Functions .....	24
4-2 Display and operator controls .....	26
4-3 Parameterisable parameters .....	27
4-4 Inputs/Outputs .....	32

## SECTION 5

<b>Transport</b> .....	<b>35</b>
5-1 Packaging/Transportation damage .....	36
5-2 Storage .....	36
5-3 Scope of delivery .....	36

## SECTION 6

<b>Assembly</b> .....	<b>37</b>
6-1 Safety notes .....	38
6-2 Sensor assembly .....	38

# TABLE OF CONTENTS

## SECTION 7

<b>Electrical Connection</b> .....	<b>41</b>
7-1 Safety notes .....	42
7-2 Establishing electrical connection .....	42
7-3 Connection diagrams .....	43
7-4 Connection in line with EMC requirements .....	45

## SECTION 8

<b>Setting into Operation</b> .....	<b>47</b>
8-1 Safety notes .....	48
8-2 Switching on the operating voltage .....	48
8-3 Aligning the sensor .....	49
8-4 Setting the switching points .....	50

## SECTION 9

<b>Parameterisation</b> .....	<b>51</b>
9-1 Parameterisation by push button directly on the sensor .....	52
9-2 Parameterisation with a PC .....	60

## SECTION 10

<b>Maintenance and Repair</b> .....	<b>61</b>
10-1 Maintenance .....	62
10-2 Repair .....	62

## SECTION 11

<b>Accessory Parts</b> .....	<b>63</b>
11-1 Accessory parts .....	64

## SECTION 12

<b>Appendix</b> .....	<b>65</b>
12-1 Error messages .....	66
12-2 Factory default parameterisation .....	67

# SECTION 1

## Important Precautions

1-1	Using the operating instructions .....	6
1-2	Use in accordance with the intended purpose .....	6
1-3	Use that is not in accordance with the intended purpose .....	6
1-4	Electromagnetic compatibility (EMC) .....	6
1-5	Warranty and liability .....	7
1-6	Key to symbols .....	7
1-7	Abbreviations .....	7

## 1-1 Using the operating instructions

These operating instructions refer exclusively to diffuse reflective sensors in the **E3NT** type series. They contain the most important notes for operating the sensor in line with safety requirements.

The operating instructions must always be close at hand and accessible at all times, and must be kept together with the higher-level machine installation.

The contents of these operating instructions must be read and understood, and all its points must be followed, by everyone who is responsible for machine planning, assembly and operation. This particularly applies to the safety notes.

Observance of the safety notes will help to avoid accidents, malfunctions and faults.

## 1-2 Use in accordance with the intended purpose

Diffuse reflective sensors in the **E3NT** type series are always operated as part of a higher-level overall system, e.g. a machine installation.

They may only be used as optical sensors to check the presence of objects within a machine installation with a higher-level control system.

Any other use, or any use exceeding this scope, is not permitted.

Use in accordance with the intended purpose also includes observance of the operating instructions and keeping to the inspection and maintenance specifications in accordance with the system documentation.

## 1-3 Use that is not in accordance with the intended purpose

Diffuse reflective sensors in the **E3NT** type series must not be used as safety components within the scope of the EU machine guideline.

Its use in applications in which the safety of persons depends on functioning of the sensor is not permissible!

## 1-4 Electromagnetic compatibility (EMC)

Diffuse reflective sensors in the **E3NT** type series conform to the following standards:

- EN 60947-5-2 Low-voltage switch gear - Part 5-2:  
Control devices and switching elements: proximity switches
- EN 50081-2/-1 Basic interference emission standard  
Industrial area/small establishments
- EN 61000-6-2 Basic interference immunity standard  
Industrial area

## 1-5 Warranty and liability

Our Terms and **Conditions of Delivery and Payment** fundamentally apply. These are available to the owner at the latest as from conclusion of a contract. Warranty and liability claims for personal injury and property damage are ruled out if they are attributable to one or several of the following causes:

- Use of the sensor that is not in accordance with its intended purpose.
- Improper assembly, commissioning and maintenance of the sensor
- Failure to observe the notes in the operating instructions in relation to transport, storage, assembly, commissioning and maintenance of the sensor
- Unauthorised structural changes to the sensor
- Repairs carried out improperly
- Disasters resulting from the influence of foreign bodies and acts of God.

## 1-6 Key to symbols

The following symbols are used in these operating instructions:



Important information



Risk of damage to the machine or material



Risk of injury to life and limb in general

## 1-7 Abbreviations

The following abbreviations are used in these operating instructions:

- **BGS** BackGround Suppression
- **FGS** ForeGround Suppression
- **IR** InfraRed
- **PC** Personal Computer





## **SECTION 2**

### **Safety Notes**

2-1	Safety notes .....	10
-----	--------------------	----

## 2-1 Safety notes



The diffuse reflective sensors belonging to the **E3NT** type series may only be used as described in these operating instructions. They may only be operated as part of a higher-level overall system, e.g. a machine installation.



During machine planning and the use of diffuse reflective sensors belonging to the **E3NT** type series, the safety and accident prevention regulations that are specific to use must be observed, e.g.:

- EN 292, Safety of machines, general design principles
- EN 60204, Electrical equipment of machines



Diffuse reflective sensors belonging to the **E3NT** type series must not be used as safety components within the scope of the EU Machine guidelines. Their use in applications in which the safety of persons depends on functioning of the sensor is not permissible!



The manufacturer and owner of the higher-level overall system, e.g. of a machine installation, is responsible for conformity with the national and international safety and accident prevention regulations that apply to the special application.



Assembly, electrical connection and maintenance may only be carried out by instructed, trained and authorised specialist personnel in accordance with applicable regulations after de-energising the power supply and switching off the machine.

**The machine must be safeguarded against reactivation.**



Conversions and changes as well as tampering with the interior of the sensor, the data link and the alignment tool are forbidden. The notes contained in these operating instructions, in particular the chapters entitled **Safety notes** and **Maintenance and repair**, must be integrated into the operating instructions of the higher-level overall system.

## SECTION 3 Specification

3-1	Diffuse reflective sensor . . . . .	12
3-1-1	General data . . . . .	12
3-1-2	Optical data . . . . .	12
3-1-3	Mechanical data . . . . .	13
3-1-4	Electrical data . . . . .	14
3-1-5	Standards and approvals . . . . .	15
3-1-6	Parallel operating range . . . . .	16
3-2	Optical data link E3NT-AL232 (order separately) . . . . .	17
3-3	Dimensions . . . . .	18
3-3-1	Sensor E3NT-L@1 with vertical connector . . . . .	18
3-3-2	Sensor E3NT-L@1 with horizontal connector . . . . .	19
3-3-3	Universal mounting bracket E39-EL1 (order separately) . . . . .	20
3-3-4	Adapter bracket E39-EL2 (order separately) . . . . .	20
3-3-5	Optical data link (order separately) . . . . .	21

## 3-1 Diffuse reflective sensor

### 3-1-1 General data

Sensor type	Diffuse reflective sensor with background respectively foreground suppression
Signal evaluation	Double triangulation method
Options	Window heating, analogue output
Parameterisation	By push button on the sensor or with a PC connected via the optical data link (order separately)
Operating modes	Background suppression, foreground suppression, background and foreground suppression (2-point window evaluation)
Optical data link (order separately)	Parameterisation via a PC, real-time analog value output, firmware update

### 3-1-2 Optical data

Emitted light	Infrared, 850 - 880 nm
Rated sensing distance	2 m
Function reserve	Factor 1.5
Setting distance $S_r$	parameterisable/teachable 0.2 ... 2.0 m (90 % remission) 0.2 ... 1.7 m (6% remission)
Standard measured object	Kodak grey card 90%, 200 x 200 mm
Blind zone	< 0.1 m
Black/white error (6%/90%)	< 10 % (of rated setting distance $S_r$ )
Hysteresis	< 5 % (of rated setting distance $S_r$ )
Repetition accuracy	< 5 % (of rated setting distance $S_r$ )
Light spot diameter	< 40 mm in the case of $S_r = 2$ m
Minimum object size	> 40 mm
Ambient light immunity to EN 60947-5-2 Halogen lamps (100-120 Hz) Fluorescent lamps (30 kHz) Energy saving lamps	> 10,000 lux > 5,000 lux > 2,000 lux (max. illuminance of an energy saving lamp)
Mutual influence	none; can be fitted in rows at this height without a clearance

### 3-1-3 Mechanical data

<b>Table 3 Mechanic data</b>	
Dimensions (length x width x depth)	85 x 27 x 65 mm
Materials	
Housing	Powder-coated aluminium, sea-water resistant, 231 GD AISi12 (Cu) (standard version)
Front pane	Aluminium with foodstuff-approved coating (option)
Keyboard	Glass
Seals	HTV silicone RTV silicone
Housing colour	Grey, RAL 7030
Assembly	Screw fastening by way of four M5 threads and two M5 through holes or with universal mounting bracket (order separately)
Connection	M12 connector, 5-pole (piercing)
Ambient temperature range	- 40 °C ... + 55 °C (with window heating) - 25 °C ... + 55 °C - 10 °C ... + 55 °C (analogue output)
Storage temperature range	- 40 °C ... + 70 °C
Permissible relative humidity	35 % ... 95 %, no condensation
Front pane heating	optional
Degree of protection to EN 60529/IEC 529	IP 67
protection class	II (250 V AC)
Resistance to	
Vibration (to IEC 68-2-6)	± 1.5 mm, 1 h , 10 - 70 Hz
Shock (to IEC 68-2-27)	300 m/s <sup>2</sup>

### 3-1-4 Electrical data

Table 4 Electrical data	
Utilisation category to EN 60947-5-2	DC 12
Rated operating voltage	+ 24 V DC, polarised
Operating voltage range	+ 10 ... + 30 V DC
Current consumption	< 80 mA with the display off < 100 mA with the display on
Switch-on delay	< 300 ms
Inputs/outputs	Pin 2 = input (In 2) or output (Out 2) depending on parameterisation Pin 4 = output (Out 1) Pin 5 = Input (In 1) or analogue output depending on model
Outputs	Functions parameterisable (e.g. switching output, alarm output, ...)
Output circuit	Parameterisable PNP (open collector), NPN (open collector) or complementary (push-pull)
Output current	max. 100 mA
Voltage drop	< 2.0 V
Residual current	< 100 $\mu$ A
Circuit protection	Reversed power supply, overload and short-circuit (pulsed), mutual interferences
Inputs	Functions parameterisable (e.g. teach-in, trigger, test, ...)
Input circuit	Voltage input +10 V ... $U_{Supply}$
Pulse duration	min. 1 ms
Analogue output	Current output 0 ... 21 mA - 3 mA correspond to distance < 0.2 m - 4 ... 20 mA correspond to distance 0.2 m ... 2.0 m - 21 mA correspond to distance > 2.0 m (or no object)
Switch-on/off time ( $T_{ON} / T_{OFF}$ )	$\leq 2.5$ ms
Insulation resistance	20 M $\Omega$ at 500 V DC
Insulation voltage strength	1 kV AC, 50/60 Hz (1 min)
Impulse strength (insulation)	6 kV

### 3-1-5 Standards and approvals

<b>Table 5 Standard and approvals</b>	
<b>Interference withstandability</b>	
General	EN 60947-5-2 Proximity switches EN 61000-6-2 Generic interference immunity standard, industrial area
Static discharge (ESD)	EN 61000-4-2 Contact $\pm 4$ kV / air $\pm 8$ kV Function criterion A*
High-frequency electromagnetic fields (HF)	EN 61000-4-3 80 ... 1000 MHz, 10 V/m, 80 % Function criterion A*
Fast transient interference quantities (burst)	EN 61000-4-4 $\pm 2$ kV, t/th = 5/50 (ns) Function criterion A*
Impulse voltages (surge)	EN 61000-4-5 $\pm 1$ kV, t/th = 1.2/50 (ns) Function criterion B*
Conducted disturbances	EN 61000-4-6 10 V, 0.15 ... 80 MHz, 80 % Function criterion A*
<b>Interference emission</b>	
General	EN 60947-5-2 Proximity switches EN 50081-2 Generic interference emission standard, industrial area EN 50081-1 Generic interference emission standard, small establishments
Radio interference field strength	EN 55011, 30 ... 1000 MHz
Radiated radio interference power	EN 55011, 1 GHz ... 18 GHz
<b>Permits</b>	UL (pending), CSA (pending)

\*


**Function criterion A**

Normal functioning also ensured during a disturbance.

**Function criterion B**

Normal functioning ensured after a disturbance.

### 3-1-6 Parallel operating range






**3-2 Optical data link E3NT-AL232 (order separately)**


Dimensions (length x width x depth)	29.5 x 72.9 x 26.4 mm
Housing material	ABS and PMMA (IR transparent)
Housing colour	Black, RAL 9005
Assembly	Snap mounting on sensor
Connection	2 m connecting cable with 9-pole sub-D connector
Ambient temperature range	- 10 °C ... + 50 °C
Storage temperature range	- 40 °C ... + 70 °C
Permissible relative humidity	35 % ... 85 %, no condensation
Degree of protection to EN 60529 / IEC 529	IP 54
Emitted light	IR communication element 880 nm
Rated operating voltage	Via RS232 interface from PC
Current consumption	6 mA

### 3-3 Dimensions


#### 3-3-1 Sensor E3NT-L□1 with vertical connector




3-3-2 Sensor E3NT-L□1 with horizontal connector




**3-3-3 Universal mounting bracket E39-EL1 (order separately)**



**3-3-4 Adapter bracket E39-EL2 (order separately)**



3-3-5 Optical data link (order separately)





## SECTION 4 Function


4-1	Functions . . . . .	24
4-2	Display and operator controls . . . . .	26
4-2-1	LED display . . . . .	26
4-2-2	LEDs . . . . .	26
4-2-3	Push buttons on the sensor . . . . .	27
4-2-4	Parameterisation via a PC . . . . .	27
4-3	Parameterisable parameters . . . . .	27
4-3-1	Mode . . . . .	28
4-3-2	Output function . . . . .	29
4-3-3	Switching points . . . . .	29
4-3-4	Output switching . . . . .	29
4-3-5	Function of connector pin 2 . . . . .	30
4-3-6	Switch-on and off delay . . . . .	30
4-3-7	Switch-off response . . . . .	30
4-3-8	Emission modulation . . . . .	30
4-3-9	Type of display . . . . .	31
4-3-10	Keyboard lock . . . . .	31
4-3-11	ECO energy saving mode . . . . .	31
4-3-12	Direction of the display . . . . .	31
4-3-13	Reset . . . . .	31
4-4	Inputs/Outputs . . . . .	32
4-4-1	Inputs . . . . .	32
4-4-2	Outputs . . . . .	33

## 4-1 Functions

Parameterisable diffuse reflective sensors in the **E3NT** type series can be operated with background and foreground suppression. Genuine **window** evaluation can also be parameterised. The distance is evaluated in accordance with the double triangulation principle. In this case, the distance from the measured object is determined not only via the intensity of the reflected emitted light, but also via the angle between the emitter, the measured object and the receiver.

- i



Contrary to sensors with single triangulation, in the case of the **E3NT** with double triangulation the measured object's direction of motion may be in all three directions. Thus, the rotatory position of the sensor about its optical axis can be chosen freely (see *Figure 1 Position of the sensor*).



**Figure 1 Position of the sensor**

- i


If the light spot is not completely on the same plane target object (minimum object size) the distance is not determined and malfunction can occur (see *Figure 2 Not determined distance*). If necessary a trigger signal or timer function has to be applied.



**Figure 2 Not determined distance**

Measured objects are detected only within the parameterised and strictly limited sensing zone. Objects outside the sensing zone (depending on the parameterisation, in the background, in the foreground or outside of a window that is defined by two parameterised distance points) are ignored.



Thanks to the infrared emitted light and the very low minimum reflection factor of 6 %, objects can be detected largely independently of their colour and their surface finish. The sensor can be parameterised by push button on the unit or with a PC and the **SensorSupportSoftware S<sup>3</sup>** (order separately) via an optical data interface **E3NT-AL232** (order separately). The optical data interface operates with an IR communication element. Through the optical data interface, the analog distance data can also be transferred permanently to a PC/Laptop and stored there.

## 4-2 Display and operator controls

Operating states are displayed by a 4-digit 7-segment LED display and two LEDs.

The sensor can be operated/parameterised either by push button on the sensor or more conveniently with a PC and parameterisation software (order separately) via an optical data interface (order separately).




Figure 3 Operator controls and displays

### 4-2-1 LED display

The distance from the measured object and the names of the menu levels during parameterisation of the sensor are displayed by the 4-digit 7-segment LED display. The display appears as red digits or letters.

If the sensor is parameterised to a bar chart display, the distance from the measured object is displayed as a green LED bar chart.

### 4-2-2 LEDs

The switching status and the stability of the two inputs are signalled as follows by two LEDs:

- Status LED
  - ON: Parameterisation menu selected
  - Blinking: Menu level with change of setting distance
  - OFF: RUN (normal) mode
  
- Red LED
  - ON: Object stably detected
  - Blinking: Object not stably detected
  - OFF: No object within range
  
- Yellow LED
  - ON: Object stably detected
  - Blinking: Object not stably detected
  - OFF: No object within range

The LEDs are visible in the display and also from the front of the sensor.

### 4-2-3 Push buttons on the sensor

On the sensor, there are three push buttons for parameterisation of the sensor (see *Figure 3 Operator controls and displays*):

- Minus key      ⊖
- Plus key        ⊕
- Enter key      ●

With these three push buttons, the operator moves through the sensor's menu and sets the parameters in accordance with the application. Therefore, the most important parameters can be set directly on the sensor.

### 4-2-4 Parameterisation via a PC

All parameters of the sensor can be set with a PC and the **OMRON SensorSupportSoftware S<sup>3</sup>**. The connection between the sensor and the PC is established via an optical data interface. The data interface is connected to a free COM port of a PC/laptop.

Refer to the separate operating instructions ABBO 0018 for further information on parameterisation with a PC and the **SensorSupportSoftware S<sup>3</sup>**.

## 4-3 Parameterisable parameters

The following parameters can be parameterised by push button on the sensor or with a PC and the parameterisation software (order separately) via the optical data interface (order separately):

- Mode
- Output function
- Teach/parameterise switching points
- Output switching
- Function on connector pins 2 and 5
- Switch-on and off delay
- Type of switch-off time function
- Emitter modulation
- Type of display on the sensor
- Keyboard lock
- Energy saving mode
- Display direction
- Reset to factory defaults

The following functions can only be parameterised with a PC and the parameterisation software (order separately) via the optical data interface (order separately):

- Complete sensor locking with/without display
- Counting function

### 4-3-1 Mode

The diffuse reflective sensor can be operated in the following modes:

- Background suppression **BGS** (factory default)  
 Measured objects are detected as from the blind zone up to the parameterised or teached switching point  $S_A$ . Objects in the background, behind the parameterised or teached switching point, are ignored.




Figure 4 Background suppression

Accordingly for output 2 the switching point C ( $S_C$ ) is set.

- Foreground suppression **FGS**  
 This mode can be parameterised separately for both outputs.  
 Measured objects are detected as from the parameterised or teached switching point  $S_A$  up to the maximum sensing distance. Objects in the foreground, between the sensor and the parameterised or teached switching point, are ignored.




Figure 5 Foreground suppression

- **Window** evaluation

Measured objects are detected only in the measurement window between the two parameterised or taught switching points (switching zone). Objects outside of this measurement window in the foreground and in the background are ignored.

**Window** evaluation involves logical AND combination of the **FGS** and **BGS** modes.





Figure 6 Window evaluation

 Accordingly for output 2 the switching points C and D are set.

### 4-3-2 Output function

The output function can be parameterised separately for both outputs:

- Light on (factory default)  
The output is active when one measured object is detected.
- Dark on  
The output is active when no measured object is detected.

### 4-3-3 Switching points

The switching points can be taught on a positioned measured object or can be parameterised by input of switching points.

In the **window** evaluation mode, two switching points must be defined for each output.

In the **FGS** or **BGS** mode, only one switching point needs to be defined.

### 4-3-4 Output switching

Output switching can be parameterised jointly for both outputs:

- PNP, plus-switching, open collector (factory default)
- NPN, minus-switching, open collector
- Push-pull, complementary, plus/minus-switching

See SECTION 7-3 Connection diagrams.

### 4-3-5 Function of connector pin 2

Pin 2 of the connector can be parameterised as Output 2 (OUT 2), as an alarm output, as a teaching input for switching points A and B or as a test input.

### 4-3-6 Switch-on and off delay

One switch-on delay and one switch-off delay each can be parameterised in ms for each output. The parameterisable time is between 0 ms and 9999 ms.

### 4-3-7 Switch-off response

This defines the switch-off response (light-on mode):

- Switch-off delay  
The switch-off delay starts as from the time when the measured object leaves the sensing zone. The output does not become inactive until the switch-off delay has elapsed.
- Minimum pulse width  
After detection of a measured object, the output remains active for at least the parameterised switch-off delay. If the measured object dwells in the sensing zone for longer than the parameterised switch-off delay, the output becomes inactive immediately after the object leaves the sensing zone.
- Constant pulse width  
After detection of a measured object, the output only remains active during the parameterised switch-off delay and becomes inactive after this time has elapsed, regardless of the measured object's dwell time, even if the measured object stays in the sensing zone for longer than the parameterised switch-off delay.

### 4-3-8 Emission modulation

Two different emission modulations can be parameterised to avoid mutual interference by adjacent or opposite sensors. Thus, two sensors can be fitted directly adjacently without them influencing or interfering with each other.

### 4-3-9 Type of display

The measured distance can be displayed on the sensor's display in two different ways:

- Absolute  
The absolute distance between the sensor and the measured object is displayed with red digits in mm.
- Bar  
The distance between the sensor and the measured object is displayed as a green bar chart.  
The switching points in the **BGS/FGS** or **window** evaluation mode are indicated by red markings next to the green bar chart.

### 4-3-10 Keyboard lock

With the keyboard lock function, the push buttons on the sensor can be locked to prevent inadvertent modification of the settings.

The lock can be activated and deactivated on the sensor.

When the keyboard lock is active, changes can only be made if the Minus ⊖ and Plus ⊕ keys have been pressed simultaneously for 4 seconds. This temporarily suppresses keyboard locking. If no key is pressed for about 5 minutes, the keyboard lock is automatically activated again.

### 4-3-11 ECO energy saving mode

In the ECO mode, the display switches off automatically approximately 5 minutes after the push buttons have been pressed for the last time.

The display is activated again the next time the push buttons are pressed.

Deactivation of the sensor display reduces the sensor's current consumption by approximately 20 mA.

### 4-3-12 Direction of the display

To improve readability, the display can be rotated by 180° when fitted. It is then "upside down".

### 4-3-13 Reset

Reset returns the sensor to the factory default settings.

## 4-4 Inputs/Outputs

In total, the sensor can be operated with a maximum of three inputs/outputs. The functions of the inputs/outputs can be parameterised.

Connector pin 4 is always defined as Output 1 (OUT 1).

Connector pin 2 can be parameterised as Output 2 (OUT 2), as the alarm output (ALARM), as the teaching input (TEACH) for switching points A or B, as test input (TEST), or as trigger input (TRIG).

Connector pin 5 can be parameterised as a trigger input (TRIG); as a teaching input (TEACH) for switching points A to D or as a test input (TEST)

### 4-4-1 Inputs

#### 4-4-1-1 Teaching input TEACH

Connector pins 2 and 5 can be parameterised as teaching inputs for the switching points A to D.

If a signal in the operating voltage range is applied to this input, the sensor is taught the switching point A, B, C or D depending on the parameterisation.

#### 4-4-1-2 Test input TEST

Connector pins 2 and 5 can be parameterised as test inputs.

The emitter is deactivated if a signal in the operating voltage range is applied to this input.

If a measured object is located in the sensor's detection zone, regardless of the parameterised switching points the receiver detects the absence of the emitted light reflected by the measured object.

Depending on the object positively the output status is altered.

#### 4-4-1-3 Trigger input TRIG

Connector pin 2 and pin 5 can be parameterised as a trigger input.

If a signal in the operating voltage range is applied to this input, the sensor is prompted to output a measurement result (object distance)



The sensor/switching speed can be increased by the trigger function



## **4-4-2 Outputs**

### **4-4-2-1 Switching outputs OUT 1 and OUT 2**

When a measured object is detected, the switching outputs OUT 1 (Connector pin 4, fixed) and OUT 2 (Connector pin 2) switch in accordance with the sensor's parameterisation.

### **4-4-2-2 Alarm output ALARM**

Connector pin 2 can be parameterised as the alarm output.

This input serves as a soiling display and as a function reserve display. It becomes active if the emitted light received and reflected by the measured object falls below a limit.



## **SECTION 5**

### **Transport**

5-1	Packaging/Transportation damage .....	36
5-2	Storage .....	36
5-3	Scope of delivery.....	36

## **5-1 Packaging/Transportation damage**

- Do not damage the sensor by other objects during transportation
- Only ever use the sensor's original packaging sealed properly for transportation
- Keep the sensor's original packaging for later use
- Report transportation damage immediately in writing to the haulage contractor and **OMRON**

## **5-2 Storage**

- Only ever store the sensor in original packaging that has been sealed properly
- Protect against dust and moisture

## **5-3 Scope of delivery**

The sensor's scope of delivery consists of:

- Diffuse reflective Sensor **E3NT-L**
- Short-form instructions
- Operating instructions on CD-ROM

# SECTION 6

## Assembly

6-1	Safety notes . . . . .	38
6-2	Sensor assembly . . . . .	38
6-2-1	Sensor's assembly direction . . . . .	39
6-2-2	Assembly via assembly holes . . . . .	40
6-2-3	Assembly by universal mounting bracket E39-EL1 . . . . .	40
6-2-4	Assembly with adapter bracket E39-EL2 and universal mounting bracket E39-EL140	

## 6-1 Safety notes



Assembly, electrical connection and maintenance must only be carried out by instructed, trained and authorised specialist personnel in accordance with applicable regulations, after de-energising the power supply and with the machine switched off.

**The machine must be safeguarded against reactivation.**



Conversions and changes and tampering in the interior of the sensor, the data interface and the alignment tool are forbidden.



During assembly, do not knock on the sensor or drop it.



The ambient conditions at the assembly location must conform to the technical data (see SECTION 3 Specification).

## 6-2 Sensor assembly



Contrary to sensors with single triangulation, in the case of the **E3NT** with double triangulation the measured object's direction of motion may be in all three directions. Thus, the rotatory position of the sensor about its optical axis can be chosen freely (see Figure 1 Position of the sensor).




Figure 1 Position of the sensor



If the light spot is not completely on the same plane target object (minimum object size) the distance is not determined and malfunction can occur (see Figure 2 Not determined distance). If necessary a trigger signal or timer function has to be applied.





Figure 2 Not determined distance

The sensor must be fitted so that:

- It is aligned to the later sensing position
- It is protected as far as possible against vibration and shock
- It is protected as far as possible against extraneous incident light
- It is protected as far as possible against damage and soiling
- Electrical connection is possible
- It is as accessible as possible for maintenance work
- Operation of the push buttons is possible
- The display is visible.


### 6-2-1 Sensor's assembly direction

As far as possible, the sensor's optical surface should be aligned parallel to the surface of the measured object.



**Figure 3 Parallel alignment**

- i** If the measured object has a glossy, reflecting surface, the sensor's optical system should be tilted by 5 ... 10° in relation to the surface of the measured object



**Figure 4 Alignment for glossy surfaces**

- ⓘ If there is a reflecting surface in parallel with the sensor's optical axis, this might lead to unstable states.  
Therefore, reflecting objects within the sensor's optical axis should be avoided.  
If this should not be possible, the reflecting surface should not be parallel to the sensor's optical surface, but should be rotated by at least 10°.

### 6-2-2 Assembly via assembly holes

1. Expertly produce securing holes/threaded holes corresponding to the six possible assembly holes of the sensor (*see Section 3-3 Dimensions*).
2. Expertly attach the sensor with suitable securing material.
3. Roughly align the sensor to the possible position of the measured object.
4. Tighten the securing screws

### 6-2-3 Assembly by universal mounting bracket E39-EL1



1. Expertly produce securing holes / threaded holes according to the required assembly holes of the universal mounting bracket (*see Section 3-3 Dimensions*).
2. Using the included securing material, expertly fit the sensor on the mounting bracket.
3. With suitable securing material, expertly fit the mounting bracket on the body of the machine.
4. Roughly align the sensor to the possible position of the measured object.
5. Tighten the securing screws.

### 6-2-4 Assembly with adapter bracket E39-EL2 and universal mounting bracket E39-EL1



Applying the adapter bracket E39-EL2 the universal mounting bracket E39-EL1 can be used as an adapter plate to mount the E3NT to existing holes.

1. Mount the bracket E39-EL1 to the existing assembly holes on the machine, if necessary produce additional ones.
2. Using the included securing material of the E39-EL1 expertly fit the sensor to the adapter bracket E39-EL2.
3. Using the included securing material expertly fit the adapter bracket to the universal mounting bracket E39-EL1



# SECTION 7

## Electrical Connection

7-1	Safety notes . . . . .	42
7-2	Establishing electrical connection. . . . .	42
7-3	Connection diagrams. . . . .	43
7-3-1	Output circuits . . . . .	43
7-3-2	Input circuits . . . . .	44
7-3-3	Connector pin assignments . . . . .	45
7-4	Connection in line with EMC requirements . . . . .	45

## 7-1 Safety notes



Assembly, electrical connection and maintenance must only be carried out by instructed, trained and authorised specialist personnel in accordance with applicable regulations, after de-energising the power supply and with the machine switched off.

**The machine must be safeguarded against reactivation.**



Conversions and changes and tampering in the interior of the sensor, the data interface and the alignment tool are forbidden.

- ! A technical data of the supply voltage and of the input/output wires must conform to the technical data of the sensor (see sensor rating plate and SECTION 3 Specification).
- ! Do not lay the sensor's connecting leads in the direct proximity of cables carrying higher voltages or together with cables that switch inductive or capacitive loads.
- ! A power supply unit that does justice to the EMC requirements must be used.
- ! The operating voltage must lie within the applicable operating voltage range. Unstabilised full or half-wave rectifiers must not be used for the power supply.
- ! The electrical connection must conform to EMC requirements.
- ! The equipotential bonding system for the machine must be produced in conformity with EN 60204-1, Section 8 "Equipotential bonding".
- ! Check the operability of all equipotential bonding conductors in conformity with Section 20 of EN 60204-1 before releasing the machine for operation.

## 7-2 Establishing electrical connection

1. Establish electrical connection in conformity with the pin assignments described in SECTION 7-3 Connection diagrams.
2. Expertly establish the equipotential bonding system, the protective earthing, the shielding and the sensor wiring in line with EMC requirements (see *Section 7-4 Connection in line with EMC requirements*).

## 7-3 Connection diagrams

### 7-3-1 Output circuits




Figure 1 Push-pull output circuit (OUT1 at pin 4 / OUT2 at pin 2)

The sensor is parameterised at the factory to a PNP output.  
The output circuit is resistant to short-circuits and reversed power supply.




Figure 2 PNP/NPN output circuit

When use is made of the PNP or NPN output circuit, the output circuit that is not currently in use is deactivated. In case of complementary output NPN or PNP are activated alternatively.

The output circuit is resistant to short-circuits and reversed power supply.

### 7-3-2 Input circuits

The sensor inputs are realized in positive logic and detect a positive voltage level of more than 1 ms duration as a valid signal if the voltage level is between 10 V and power supply voltage.




Figure 3 Input circuit input 1 (IN1 at pin 5)






Figure 4 Input circuit input 2 (IN2 at pin 2)

 Pin 2 can be set as input or output (factory default)

### 7-3-3 Connector pin assignments

The sensor is connected by means of a standardised 5-pole M12 connector (see *Figure 5 Connector pin assignments*).



(View of connector pins on the sensor)

**Figure 5 Connector pin assignments**

## 7-4 Connection in line with EMC requirements

- In environments with interference levels, use cables with twisted-pair wires and/or shielded cables.
- When cables are introduced into an EMC control cabinet, guide the cable shield without interruption through the wall of the EMC control cabinet (e.g. via a cable conduit).
- Expertly connect the cable shield to the control cabinet housing (flat surface, conductive).
- Expertly connect wires of cables or free cable ends that are not used to the cable shield on both ends of the cable.
- If the control cabinet is connected by means of connectors, use connectors with a metal housing and a leading protective earth contact (in accordance with EN 60204-1) only.
- Conductively connect the cable shield to the connector housing.
- Expertly connect the mating connector to the control cabinet housing (flat surface, conductive).
- Route supply and signal leads in separate cable ducts.
- Route supply and signal leads as closely as possible to the equipotential bonding conductor.
- Do not route cable ducts in the proximity of strong electromagnetic interference sources such as electric motors or transformers.
- Suitable protective measures conforming to EN 60204-1 must be taken if the cable layout does not fully rule out the risk of lightning strikes.



# SECTION 8

## Setting into Operation

8-1	Safety notes . . . . .	48
8-2	Switching on the operating voltage. . . . .	48
8-3	Aligning the sensor . . . . .	49
8-4	Setting the switching points . . . . .	50
8-4-1	Teaching the switching points in the normal mode . . . . .	50
8-4-2	Parameterising the sensor . . . . .	50

## 8-1 Safety notes



The diffuse reflective sensors in the **E3NT** type series may only be used as described in these operating instructions. They may only be operated as part of a higher-level overall system, e.g. of a machine installation.



Diffuse reflective sensors in the **E3NT** type series must not be used as safety components within the scope of the EU machine guideline. Their use is not permitted in applications in which the safety of persons depends on functioning of the sensor!

## 8-2 Switching on the operating voltage

After the operating voltage has been switched on, the sensor runs a power-on reset with a self-test.

The sensor displays the current distance from the measured object if the self-test is successful.



0--0 is displayed if the sensor does not detect a measured object.




The flashing display ---- appears in the event of a short-circuit at the outputs.

The sensor continues normal functioning once the short-circuit at the outputs has been remedied.




## 8-3 Aligning the sensor

 Owing to the infrared emitted light, the light spot on the measured object is not visible.

This is why the sensor must be aligned according to the optical axis.

The alignment marking on the top of the sensor can be used as a sighting line for the optical axis, thus simplifying alignment (see *Figure 1 Aligning the sensor*).

1. Position the measured object at the required position before the sensor.
2. Undo the securing screws.
3. Align the sensor's optical axis/alignment marking to the measured object.
4. Tighten the securing screws.
5. Check alignment once again.



**Figure 1** Aligning the sensor

## 8-4 Setting the switching points

The switching points can either be taught (Teach-in mode) with a measured object positioned at the corresponding distance or can be parameterised by input.

For each output of the sensor (up to two), up to two switching points can be taught or parameterised.

Only ever one switching point is active in the foreground and background suppression modes.

For the 2-point window evaluation mode, two switching points must be set.

### 8-4-1 Teaching the switching points in the normal mode



The sensor is set at the factory for both outputs set to **BGS**, light on.

1. Place the target object in front of the sensor at the desired position.
2. Teach the switching point for output 1:
  - Beginning with the  $\oplus$  key, press it together with the ENTER  $\bullet$  key at the same time. Threshold level is thought and the output/LED is updated. Status LED is blinking.
  - Using the  $\oplus/\ominus$  keys an adjustment of the switching point is possible. The output/LED is updated immediately.
  - Pressing the ENTER  $\bullet$  key for more than 2 seconds or after 2 minutes without any activation of the keys, finish the teach mode and the sensor returns to normal operation. The status LED is turned off.
3. Teach the switching point for Output 2:
  - Beginning with the  $\ominus$  key, press it together with the ENTER  $\bullet$  key at the same time.

### 8-4-2 Parameterising the sensor

The sensor's parameters and the four possible switching points are set as described in Section 9-1 *Parameterisation by push button directly on the sensor* or Section 9-2 *Parameterisation with a PC*.

# SECTION 9


## Parameterisation

9-1	Parameterisation by push button directly on the sensor . . . . .	52
9-1-1	Display in the normal mode . . . . .	52
9-1-2	Main menu structure . . . . .	53
9-1-3	TEACH menu path . . . . .	54
9-1-4	SET menu path . . . . .	56
9-1-5	OPTIONS menu path . . . . .	58
9-2	Parameterisation with a PC . . . . .	60

## 9-1 Parameterisation by push button directly on the sensor

The sensor is parameterised by means of three push buttons.


With these push buttons, the user navigates through the parameterisation menus, where all necessary sensor settings can be made.


-  If no keys are pressed for 2 minutes during parameterisation, you are returned automatically to the normal mode.

### 9-1-1 Display in the normal mode

Depending on the parameterisation, the sensor's display shows the following in the normal mode:

- Status LED is turned off.
- Digital display:  
The current distance from the sensor to the measured object in m.
- Bar display:  
The current distance from the sensor to the measured object as a bar

-  The display show  $\bar{\bar{0}}$  if the sensor does not detect a measured object.

-  The flashing display ---- appears the event of a short-circuit at the output  
The sensor continues normal functioning when the short-circuit at the outputs is eliminated.

### 9-1-2 Main menu structure

The following figure shows the main menu structure of the main parameterisation level.









Figure 1 Menu structure of the main parameterisation level

When the Enter ● key is pressed for 2 seconds, the sensor switches from the normal mode to the **TEACH** menu path. The sensor switches to each next menu path when the Enter ● key is repeatedly pressed for 2 seconds. In the menu paths, the required parameters can be selected by pressing the ⊖ and ⊕ keys.

- 
 To skip a menu path, you can also press the Enter ● key for 4 seconds.
- 

 Press the Enter ● key < 1 second.
- 

 Press the Enter ● key > 2 seconds.

### 9-1-3 TEACH menu path

The switching points of the outputs are taught or parameterised in the **OPTIONS** menu path. The Status LED is on and is blinking during setpoint settings.




Figure 2 TEACH menu path

**Remarks**

1. In the 2-point window evaluation mode, two switching points (A/B and C/D) can be set for each output.  
In the foreground and background suppression modes, only one switching point (A and C) can be set for each output. Then, only the outputs A and C can be set in the **TEACH** menu path. The parameters for B and D do not apply.
2. If Connector pin 2 is set as in input, only the switching points for Output 1 can be set.

### 9-1-4 SET menu path

All function parameters of the sensor are defined in the SET menu path.  
The Status LED is on.




Figure 3 SET menu path



**Remarks**

1. If Connector pin 2 is set as an input, the switch-on/off delay function can only be set for Output 1. Then, a second switching output is not available.
2. If the switch-on/off delay is off in the **OPTIONS** menu path, the switch-on/off delay parameters do not appear in the **SET** menu path.
3. The outputs behave differently depending on the switch-off delay function that is set in the **OPTIONS** menu path.
4. If the key lock is on, it becomes active when no keys have been pressed for about 5 minutes.  
The key lock can be temporarily cancelled by pressing the ⊖ and ⊕ keys for 2 seconds.

### 9-1-5 OPTIONS menu path

All function options of the sensor are defined in the **OPTIONS** menu path. The Status LED is on.




Figure 4 OPTIONS menu path

**Remarks**

1. If Connector pin 2 is set as an input, the type of switch-on/off delay can only be set for Output 1.
2. If the ECO energy saving mode is on, the display is switched off if no keys are pressed for about 5 minutes.  
The display is switched on again when any key is pressed.

## 9-2 Parameterisation with a PC

All parameters of the sensor can also be set with a PC and the **OMRON SensorSupportSoftware S<sup>3</sup>**.

The connection between the sensor and the PC is established via an optical data interface. The data interface is clipped onto the sensor and is connected to a free COM port on the PC/laptop via the interface cable.

Data communication with the PC can be used for the following functions:

- Sensor parameterisation and configurations
  
- Real time readout
  - of the object distance
  - of switching states
  - of the stability
  - of the alarm outputs
  
- Monitoring and archiving the sensor data
  
- Updating the sensor firmware  
That means, a later or customised version of the sensor's operating program can be transferred to the sensor.

Refer to the separate operating instructions ABBO 0018 for further information on parameterisation with a PC and the **SensorSupportSoftware S<sup>3</sup>**.

# SECTION 10 Maintenance and Repair

10-1 Maintenance .....	62
10-2 Repair .....	62

## 10-1 Maintenance



Assembly, electrical connection and maintenance may only be carried out by instructed, trained and authorised specialist personnel in accordance with applicable regulations, after de-energising the power supply and with the machine switched off.

**The machine must be safeguarded against reactivation.**

- ! Do not use any scratching or abrasive cleaning materials. The protective pane of the optical system might get damaged.

The sensor requires no maintenance.

Remove soiling from the optical system and the display at regular intervals with a soft fabric.

## 10-2 Repair

The sensor, the optical data interface and the alignment tool may only be repaired by the manufacturer.

Send in the sensor and the optical data interface tool to the supplier for repair along with a description of the fault.

# **SECTION 11**

## **Accessory Parts**

11-1 Accessory parts .....	64
----------------------------	----

## 11-1 Accessory parts

<b>Description</b>	<b>Article number</b>
Universal mounting bracket	E39-EL1
Adapter bracket	E39-EL2
IR data interface, cable length 2 m	E39-AL232 2m
Straight cable socket, 5-pole, 2 m cable length	XS2F-D521-DG0-A
Straight cable socket, 5-pole, 5 m cable length	XS2F-D521-GG0-A
L-shaped cable socket, 5-pole 2 m cable length	XS2F-D522-DG0-A
L-shaped cable socket, 5-pole 5 m cable length	XS2F-D522-GG0-A



# SECTION 12

## Appendix

12-1 Error messages .....	66
12-2 Factory default parameterisation.....	67

## 12-1 Error messages

The following error messages are shown on the sensor's display:

<b>Display</b>	<b>Meaning</b>
0--0	The sensor does not detect an object
---- (flashing)	Short-circuit at the output. The sensor continues normal functioning once the short-circuit at the outputs has been remedied.

## 12-2 Factory default parameterisation

<b>Parameter</b>	<b>Factory default parameterisation</b>
Mode of Output 1	Background suppression BGS
Mode of Output 2	Background suppression BGS
Output function of Output 1	Light-on
Output function of Output 2	Light-on
Output switching	PNP
Switch-on/off delay Outputs 1 and 2	OFF
Function of Connector pin 2	Output 2 (OUT 2)
Function of Connector pin 5	Teaching input (TEACH) for switching point A
Display	in m
Energy saving mode	OFF
Key lock	OFF
Emission modulation	type 1





# OMRON

**Authorized Distributor:**