

TABLE OF CONTENTS

Preface	
Conventions Used in This Manual	
Meanings of Abbreviations	
How to Read Display Symbols	
“Reference” mark	
Notice:	
How this Manual is Organized	
Pay Attention to the Following when Installing this Controller	
CHAPTER 1 INTRODUCTION	
This chapter introduces the E5AK. First-time users should read this chapter without fail.	
For details on how to use the controller and parameter settings, see Chapters 2 onwards.	
1.1 Names of parts	
Main parts	
Front panel	
About the displays	
How to use keys	
1.2 Input and Output	
Input	
Output	
1.3 Parameters and Menus	
Parameter types	
Selecting modes	
Selecting parameters	
Fixing settings	
1.4 About the Communications Function	
1.5 About Calibration	
CHAPTER 2 PREPARATIONS	
This chapter describes the operations you should carry out before turning the E5AK ON.	
2.1 Setting up	
Draw-out	
Setting up the output unit	
Setting up the option unit	
2.2 Installation	
Dimensions	
Panel cutout	
Mounting	
2.3 Wiring Terminals	
Terminal arrangement	
Precautions when wiring	
Wiring	
CHAPTER 3 BASIC OPERATION	
This chapter describes an actual example for understanding the basic operation of the E5AK.	

3.1	Convention Used in this Chapter
3.2	Setting Input Specifications
	Input type
	Scaling
3.3	Setting Output Specifications
	Output assignments
	Direct/reverse operation
	Control period
3.4	Setting Alarm Type
	Alarm type
	Alarm value
	Alarm hysteresis
	Close in alarm/open in alarm
3.5	Protect Mode
	Security
	A/M key protect
3.6	Starting and Stopping Operation
3.7	Adjusting Control Operation
	Changing the set point
	Manual operation
	Auto-tuning (A.T.)
	CHAPTER 4 APPLIED OPERATION

This chapter describes each of the parameters required for making full use of the features of the E5AK. Read this chapter while referring to the parameter descriptions in chapter 5.

4.1	Selecting the Control Method
	Heating and cooling control
	Position-proportional control
	ON/OFF control
4.2	Operating Condition Restrictions
	Manipulated variable restrictions
	Set point limiter
	SP ramp
4.3	How to Use Event Input
	Input assignments
	Multi-SP
	Other event input functions
4.4	How to Use the Remote SP
	Scaling
	SP mode
	Remote SP monitor
	SP tracking
	Operating conditions
4.5	How to Use the Heater Burnout Alarm
	Heater burnout detection
	Operating conditions
	How to calculate the heater burnout set value
4.6	LBA

4.7 How to Use Transfer Output
CHAPTER 5 PARAMETERS
This chapter describes the parameters of the E5AK.
Use this chapter as a reference guide
Conventions Used in this Chapter
The meaning of icons used in this chapter
About parameter display
Protect Mode
Manual Mode
Level 0 Mode
Level 1 Mode
Level 2 Mode
Setup Mode
Expansion Mode
Option Mode
Calibration Mode
CHAPTER 6 USING THE COMMUNICATIONS FUNCTION
This chapter mainly describes communications with a host computer and communications commands.
6.1 Outline of the Communications Function
Outline
Transfer procedure
Interface
6.2 Preparing for Communications
Cable connections
Setting the communications specifications
6.3 Command Configuration
6.4 Commands and Responses
Reading/writing parameters
Issuing special commands
6.5 How to Read Communications Error Information
End code
Undefined error
6.6 Program Example
How to use programs
Program list (language: IBM PC COMPATIBLE MACHINE)
Examples of use
CHAPTER 7 CALIBRATION
This chapter describes procedures for each calibration operation.
Read this chapter only when the controller must be calibrated.
7.1 Structure of Parameters
7.2 Calibrating Thermocouple
7.3 Calibrating Platinum Resistance Thermometer
7.4 Calibrating Current Input
7.5 Calibrating Voltage Input
7.6 Checking Indication Accuracy
CHAPTER 8 TROUBLESHOOTING

This chapter describes how to find out and remedy the cause if the E5AK does not function properly.....
8.1 Initial Checks
8.2 How to Use the Error Display
8.3 How to Use Error Output
8.4 Checking Operation Restrictions
AppEndix
SPECIFICATIONS
Ratings
Characteristics
Output Unit Ratings and Characteristics
Option Unit Ratings and Characteristics
ABOUT CURRENT TRANSFORMER (CT)
CONTROL BLOCK DIAGRAM
Standard type
Position-proportional type
SETTING LIST
MODEL LIST
PARAMETER OPERATIONS LIST
FUZZY SELF-TUNING
Features
Fuzzy Self-tuning Function
X FORMAT
Format
X FORMAT HEAD LIST
ASCII CODE LIST