

TABLE OF CONTENTS

SECTION 1

Introduction
1-1 Features
1-2 Models
1-3 Specifications
1-3-1 Ratings
1-3-2 Characteristics

SECTION 2

Sensor and Mode Settings
2-1 Disassembly
2-2 Output Units
2-3 Internal Switch Settings
2-3-1 Internal Switch Positions
2-3-2 Input Type Selector Setting
2-3-3 Alarm Mode Setting
2-3-4 Standby Sequence
2-3-5 Function Selector Settings
2-3-6 Key Protection Switch Settings

SECTION 3

Settings Before Operation
3-1 Nomenclature
3-2 Setting Flowchart
3-3 List of Parameters
3-4 Parameters on Display Level 0
3-5 Parameters on Display Level 1

SECTION 4

Fuzzy Self-tuning
4-1 Fuzzy Self-tuning Operation
4-1-1 Step Response Tuning (SRT)
4-1-2 Disturbance Tuning (DT)
4-1-3 Hunting Tuning (HT)
4-2 Troubleshooting
4-3 Terminology
4-3-1 Stable Value, Stable Range, and Stability Judgement Time
4-3-2 Hunting
4-3-3 Characteristics and Characteristics Change
4-3-4 External Disturbance
4-3-5 Interference
4-3-6 Startup

SECTION 5

Installation and Wiring
5-1 Installation
5-1-1 Dimensions and Mounting Holes
5-1-2 Mounting Method
5-2 Wiring
5-2-1 Connection
5-3 Terminal Arrangement

SECTION 6

Troubleshooting
6-1 Error Display and Output

TABLE OF CONTENTS

6-2 Troubleshooting

SECTION 7

Event Input Function

- 7-1 Event Input Function
- 7-1-1 Set Point Selection
- 7-1-2 RUN/STOP Selection (E5AJ-jB, E5EJ-jB)
- 7-1-3 Signal Input Method

SECTION 8

Heater Burnout Detection

- 8-1 Heater Burnout Detection
- 8-2 Heater Burnout Procedures
- 8-3 Wiring the Current Transformer
- 8-4 Heater Burnout Alarm Value
- 8-4-1 Setting Examples

SECTION 9

Engineering Level Settings

- 9-1 Engineering Level
- 9-2 Engineering Level Parameter List
- 9-3 Engineering Level Parameters

SECTION 10

Auto-tuning

- 10-1 Starting Auto-tuning
- 10-2 Conditions that Prevent Auto-tuning
- 10-3 Force-ending Auto-tuning
- 10-4 Changing Parameters during Auto-tuning

Appendices

- A Dimensions/Mounting Holes

Revision History

