

TABLE OF CONTENTS

PRECAUTIONS

- 1 Intended Audience
- 2 General Precautions
- 3 Safety Precautions
- 4 Operating Environment Precautions
- 5 Application Precautions

SECTION 1 Introduction

- 1-1 CW and CCW
- 1-2 Feedback Pulse
- 1-3 Coordinate Systems
- 1-4 Applicable Machines
- 1-5 Wiring Precautions
- 1-6 System Configuration
- 1-7 Outline of the Interface Area
- 1-8 Data Configuration
- 1-9 Programs and Tasks
- 1-10 Manual and Automatic Operation

SECTION 2 Features

- 2-1 Features
- 2-2 Specifications
- 2-3 Outside Dimensions
- 2-4 Functions

SECTION 3 Servo System Principles and Precautions

- 3-1 Servo System
- 3-2 Motor Runaway
- 3-3 Wiring Check Function
- 3-4 Failsafe Circuits

SECTION 4 System Configuration

- 4-1 Basic System Configuration
- 4-2 Items Supplied by the User
- 4-3 Peripheral Devices

SECTION 5 Positioning

- 5-1 Positioning Controls
- 5-2 PTP Control
- 5-3 Linear Interpolation
- 5-4 Circular Interpolation
- 5-5 Interrupt Inching
- 5-6 Acceleration and Deceleration Curves
- 5-7 Operation Modes
- 5-8 Override Function
- 5-9 Backlash Compensation

SECTION 6 G Language

- 6-1 Introduction
- 6-1-1 Example Program
- 6-1-2 G-language Codes
- 6-2 G-language Symbols
- 6-2-1 Specifying Position Data Addresses (A0000 to A1999)

TABLE OF CONTENTS

6-2-2 Specifying Registers (E00 to E31)

SECTION 7 Preparations for Operation

7-1 System Startup Procedures

7-2 Testing Equipment Configuration

7-3 Items to Be Prepared

7-4 Positioning Operations

7-5 Interface Area

SECTION 8 Test Operation

8-1 Mounting the Units

8-1-1 Mounting Positions

8-1-2 Mounting the Units

8-2 Connecting the Computer

8-2-1 Connecting via the Peripheral Bus for SYSMAC Support Software

8-2-2 Connecting Personal Computer for MC Support Software

8-3 Connecting the Teaching Box

8-4 Wiring I/O Connectors

8-5 Connecting Servodrivers

8-6 Wiring Input Units

8-7 Starting Up the PC

8-8 Setting Parameters

8-8-1 Selection of MC Model

8-8-2 Minimum Unit

8-8-3 Display Unit

8-8-4 Pulse Rate

8-8-5 Positive and Negative Software Limits

8-8-6 Reference Origin Offset

8-8-7 Workpiece Origin Offset Value

8-8-8 Maximum High-speed Feed Rate

8-8-9 Maximum Interpolation Feed Rate

8-8-10 Origin Search High Speed

8-8-11 Origin Search Low Speed

8-8-12 Maximum Jog Feed Rate

8-8-13 In-position Value

8-9 Saving Parameters

8-10 Transferring Parameters

8-11 Flash Memory Backup of Parameter

8-12 Creating MC Programs

8-13 Saving MC Programs

8-14 Transferring MC Programs

8-15 Flash Memory Backup of MC Program

8-16 Creating Ladder-diagram Programs

8-17 Checking Operation from the MCSS

8-18 Checking Operation from the Teaching Box

Glossary

Revision History

