

TABLE OF CONTENTS

SECTION 1

Nomenclature and Functions

- 1-1 Front Panel
- 1-2 Remote Mode and Local Mode
- 1-3 Communications Terminal Arrangements
- 1-4 Communications Terminals
- 1-5 Connections

SECTION 2

RS-232C/RS-422/RS-485 Communications

- 2-1 Interface Specifications
- 2-1-1 RS-232C
- 2-1-2 RS-422
- 2-1-3 RS-485
- 2-2 Before Operation
- 2-3 Key Operation
- 2-4 General RS-232C/RS-422/RS-485 Specifications
- 2-5 Data Specifications
- 2-6 Communications and Error Control
- 2-6-1 Communications Control Procedures
- 2-6-2 Blocks
- 2-6-3 Error Control
- 2-6-4 Precautions
- 2-7 Header Codes
- 2-8 End Code List
- 2-9 Selecting Remote and Local Mode
- 2-10 Selecting Write Modes
- 2-11 Set Point Save
- 2-12 Set Value Write
- 2-13 Set Value and Output Value Read
- 2-14 Set Point Limit Read
- 2-15 Process Value Read
- 2-16 Heater Current Read
- 2-17 Initial Status Read
- 2-18 Undefined Error
- 2-19 Communications Time
- 2-20 Communications Program Example
- 2-20-1 RS-232C/RS-422/RS-485 Communications Program Example
- 2-20-2 Operation Example

Appendices

- A ASCII Code List (ANSI x 3.4 – 1986)

Revision History