

# TABLE OF CONTENTS



## PRECAUTIONS .....

- 1 Safety Precautions .....
- 2 General Precautions .....
- 3 Export Precautions .....

## SECTION 1

### Before Installing .....

- 1-1 Installation Precautions .....
- 1-1-1 F400 Components .....
- 1-1-2 Installation Site .....
- 1-1-3 Installation .....
- 1-1-4 Cables .....
- 1-1-5 Camera .....
- 1-2 Confirming Package Contents .....
- 1-3 Product Availability .....

## SECTION 2

### Product Introduction .....

- 2-1 Component Names and Functions .....
- 2-2 Connections .....
- 2-3 Power Supply and Ground .....
- 2-3-1 Crimp Terminals and Cables .....
- 2-3-2 Protective Conductor (Earth) Wiring .....
- 2-3-3 Wiring the Power Supply .....
- 2-4 Camera .....
- 2-5 CCTV Lens .....
- 2-5-1 Optical Chart .....
- 2-5-2 Lens .....
- 2-5-3 Extension Tubes .....
- 2-6 Lighting .....
- 2-6-1 Lighting Methods .....
- 2-6-2 Light Source .....
- 2-7 Mounting the Controller .....
- 2-7-1 Mounting to DIN Track .....
- 2-7-2 Mounting on a Flat Surface .....

## SECTION 3

### Terminal Blocks .....

- 3-1 Crimp Terminals and Cables .....
- 3-2 Specifications .....
- 3-3 Terminals .....

## SECTION 4

### RS-232C Connection .....

- 4-1 Connector .....
- 4-2 Wiring .....
- 4-3 Connection .....

## SECTION 5

### Troubleshooting .....

- 5-1 Connection Errors .....
- 5-2 Errors during Menu Operation .....
- 5-3 Terminal Block Errors .....

# TABLE OF CONTENTS

5-4 RS-232C Communications Errors .....

## SECTION 6

**Inspection** .....

6-1 Regular Inspections .....

## SECTION 7

**Specifications** .....

7-1 F400 Vision Mate Controller .....

7-2 K150-KP Console .....

7-3 Camera .....

7-4 Cables .....

**Revision History** .....

