

TABLE OF CONTENTS

PRECAUTIONS	
1 General Precautions	
2 Safety Precautions	
3 Application Precautions	
4 Noise Prevention	
SECTION 1	
Introduction	
1-1 Features	
1-2 Front of the Meter	
1-3 Rear of the Meter	
1-4 Modes	
1-5 Communications Function	
1-6 Field Calibration	
SECTION 2	
Setup	
2-1 Mounting	
2-2 Base Unit	
2-2-1 Terminal Arrangement	
2-2-2 Wiring Precautions	
2-2-3 Wiring	
2-3 Output Board	
2-3-1 Terminal Arrangement	
2-3-2 Relay Output Board	
2-3-3 Transistor and Combination Output Board	
2-3-4 Linear Output Board	
2-3-5 BCD Output Board	
SECTION 3	
Parameter Setting	
3-1 Overview	
3-1-1 Heading Symbols	
3-1-2 Setting Procedures	
3-2 Setting Mode	
3-2-1 Selecting Setting Mode	
3-2-2 Menu Overview	
3-2-3 Setting Value Menu (sUset)	
HH Set Value	
H Set Value	
L Set Value	
LL Set Value	
3-2-4 Scaling Menu (scale)	
Input Value 2	
Display Value 2	
Input Value 1	
Display Value 1	
Decimal Point Position	
3-2-5 Setup Menu (setup)	
Input Range	
Power Supply Frequency	
Communications Unit Number	

TABLE OF CONTENTS

Baud Rate
Word Length
Stop Bits
Parity Bits
3-2-6 Option Menu (opt)
Average Processing
Startup Compensation Time
Hysteresis
Comparative Output Pattern
Upper Limit (H) of Linear Output Range
Lower Limit (L) of Linear Output Range
Remote/Local Programming
3-3 Protect Mode
3-3-1 Selecting Protect Mode
3-3-2 Menu Overview
3-3-3 Protect Menu (prot)
All Key Protect
Setting Value Change Prohibit
Forced-zero Prohibit
Maximum/Minimum Value Clear Prohibit
Security

SECTION 4

Operations in RUN Mode

4-1 Forced-zero
4-2 Displaying and Changing Setting Values
4-2-1 Displaying Setting Values
4-2-2 Changing Setting Values
4-3 Displaying and Resetting of Maximum and Minimum Values
4-3-1 Displaying Maximum and Minimum Values
4-3-2 Resetting Maximum and Minimum Values
4-4 External Input Signals
4-4-1 Forced-zero
4-4-2 RESET
4-4-3 HOLD

SECTION 5

Useful Functions

5-1 Teaching Function
5-1-1 Set Value
5-1-2 Scaling Value
5-1-3 Linear Output Range
5-2 Output Test
5-3 Maintenance Mode
5-3-1 Maintenance Mode
5-3-2 Initialization
5-3-3 Field Calibration
5-3-4 Reference Input Signal

SECTION 6

BCD Output

6-1 Connectors
----------------	-------

TABLE OF CONTENTS

6-2 Timing Charts

SECTION 7

Troubleshooting

7-1 Items to Be Checked First

7-2 Display

7-2-1 Flashing

7-2-2 Error Message

Appendices

A Specifications

B List of Settings

C Available Models

D Available Parameters

E Setting Examples

Index

Revision History

